

MPS 35C Air Data Test Set

Operation Instructions And User's Manual



D. Marchiori s.r.l.

Address: via Pontina km. 43.856 - 04011 Aprilia (LT) Italy
tel: ++39-06-928 2733 – fax: ++39-06-927 5401
e-mail: d.marchiori@mclink.it Internet: <http://www.dma-aero.com>

This Document is the property of D. Marchiori s.r.l., and may not be copied or otherwise reproduced, communicated in any way to third parties, nor stored in any data processing system without the express written authority of D. Marchiori s.r.l.

CONTENTS

PRELIMINARY.....	5
IMPORTANT NOTES.....	6
FIG. 1 - AIR DATA TEST SET P/N MPS 35C FRONT PANEL.....	7
FIG. 2 - LAYOUT OF HHRCU KEYBOARD AND DISPLAY.....	8
SECTION 1 - MPS 35C CONTROL KEYS.....	9
1.1 GENERAL DESCRIPTION.....	9
1.2 PHYSICAL DESCRIPTION.....	10
1.3 KEYPAD KEYS.....	10
SECTION 2 - OPERATIONAL MODES, MENUS AND DISPLAYS.....	13
2.1 CONTROL MODE.....	13
2.1.1 CONTROL MODE MENU.....	13
2.2 MEASURE MODE.....	13
2.2.1 MEASURE MODE MENU.....	13
2.3 VENT MODE.....	14
2.4 LEAK MODE.....	14
2.4.1 LEAK MODE DISPLAY.....	14
2.5 LIMITS MODE.....	14
2.5.1 LIMITS MODE MENU.....	14
SECTION 3 - START UP PROCEDURE.....	15
SECTION 4 - ENTERING AIR DATA TEST PARAMETERS INFORMATION.....	17
4.1 METHOD 1, ENTERING OF SPECIFIC COMMAND VALUES.....	17
4.1.1 ALTITUDE COMMAND.....	17
4.1.2 AIRSPEED COMMAND.....	17
4.1.3 ALTITUDE RATE COMMAND (RATE OF CHANGE).....	18
FIG. 3 - EXAMPLE OF DISPLAY LAYOUT IN CONTROL MODE.....	18
4.2 METHOD 2-VALUES COMMAND WITH DIGIT CHANGE FUNCTION.....	19
4.3 ACOUSTIC ALARM FUNCTION.....	19
SECTION 5 - ADVANCED OPERATIONS.....	20
5.1 DIFFERENT RATE COMMANDS.....	20
5.2 PRESSURE VALUES COMMAND IN DIRECT ENGINEERING UNITS	20
5.2.1 ALTITUDE COMMAND USING DIRECT PRESSURE VALUES	20
5.2.2 AIRSPEED COMMAND USING DIFFERENTIAL PRESSURE VALUES	21
5.3 SPECIFIC PITOT PRESSURE VALUE COMMAND.....	21
5.4 MACH NUMBER.....	21
5.5 LEAK TEST MODE OPERATION.....	21
5.6 MEASURE (MEAS) MODE.....	22
SECTION 6 - PRESET LIMITS AND ENGINEERING UNITS CHANGE.....	23
6.1 CHANGING PRESET LIMITS.....	23
6.2 PERMANENT MEMORISATION OF LIMITS.....	23
6.3 ENGINEERING UNITS CHANGING.....	24
6.4 ALTITUDE AND AIRSPEED RATE ENGINEERING UNITS CHANGE.....	24
SECTION 7- ULTRA LOW SPEED FUNCTION.....	25
SECTION 8 - INTERNAL BATTERY.....	26

SECTION 9 - MULTIPLE ISOLATOR	27
SECTION 10 - ANGLE OF ATTACK OPTION.....	28
10.1 GENERAL.....	28
10.2 CONNECTIONS FOR A.O.A. TEST.....	28
10.3 AIR DATA AND A.O.A. SETTING.....	28
10.4 A.O.A. MENUS.....	29
10.4.1 ALTERNATIVE A.O.A. MENU 1.....	29
10.4.2 ALTERNATIVE A.O.A. MENU 2.....	31
10.5 FUNCTIONS DEACTIVATED IN THE A.O.A. MODES.....	33
10.6 A.O.A. MODES BY DEFAULT.....	33
10.7 ANGLULAR DEGREES VERSUS PRESSURE RATIO RELATIONSHIP.....	33
10.8 A.O.A. PRESSURE ZERO ADJUSTMENT.....	34
FIG. 3 – A.O.A CONNECTION TO MPS 35C SCHEME.....	35
SECTION 11 - SAFE MANUAL OPERATION.....	36
11.1 CONDENSATE DRAINAGE SYSTEM.....	36
11.2 MANUAL VENT.....	36
SECTION 12 - SPECIAL FUNCTIONS.....	37
12.1 SETTING DISPLAY	37
12.2 QNH READING.....	37
12.3 BATTERY CHARGE STATUS	37
12.4 MPS 35C OPERATION BY MEANS OF REMOTE PC.....	37
12.5 TRUE AIRSPEED.....	37
12.6 ENHANCED RESOLUTION.....	37
12.7 DATE AND TIME.....	38
12.8 CENTER LINE CORRECTION.....	38
12.9 VALVES FINE TUNING (MAP).....	38
12.10 FINE TUNING FUNCTION.....	38
12.11 SAVING VARIABLE PARAMETERS.....	38
12.12 E.P.R. (ENGINE PRESSURE RATIO).....	38
12.13 ENCODING ALTIMETER READING (OPTION).....	39
12.14 ACTIVATING/DEACTIVATING FUNCTIONS.....	39
12.15 ACTIVATING/DEACTIVATING THE MODULATION FUNCTION.....	40
12.15 SPECIAL FUNCTIONS KEYS SUMARY.....	41
SECTION 13 - USE OF HAND HELD REMOTE CONTROL UNIT	42
FIG. 4 – HAND HELD REMOTR CONTROL UNIT.....	42
SECTION 14 - SET PROFILES.....	43
14.1 SELECTING, PROGRAMMING OR CHANGING A TEST PROFILE.....	43
14.2 EXECUTING A SELECTED TEST PROFILE.....	45
14.3 PROGRAMMING EXAMPLE.....	45
14.4 EXECUTING A.O.A SELECTED TEST PROFILE.....	46
SECTION 15 - TEST RESULTS SAVING AND TRANSFER.....	49
15.1 GENERAL	49
15.2 TEST RESULTS MEMORIZATION MODE CONFIGURATION.....	50
15.3 TEST RESULTS RECORDING.....	51
15.4 TEST RESULTS READOUT.....	52

15.5 TEST MEMORIZATION.....	52
15.6 DATA MANAGEMENT.....	52
15.7 PROFILES PROGRAMMING USING A PC VIA USB.....	52

SECTION 16 - CALIBRATION.....55

16.1 DURATION AND SERVICE.....

55

15.5 TEST MEMORIZATION.....	52
15.6 DATA MANAGEMENT.....	52
15.7 PROFILES PROGRAMMING USING A PC VIA USB.....	52

SECTION 16 - CALIBRATION.....55

16.1 DURATION AND SERVICE.....	55
--------------------------------	----

16.2 COMPANY CALIBRATION SERVICE.....	55
---------------------------------------	----

SECTION 17 - ADTS CONTROL PARAMETERS FOR VARIABLE TUNING.....56

18 - TECHNICAL SPECIFICATIONS.....57

18.1 AIR DATA FUNCTIONS.....	57
18.2 ACCURACY.....	57
18.4 DIMENSIONS.....	58
18.5 ENVIRONMENTAL.....	58
18.6 CALIBRATION.....	58
18.7 SELF TEST TIME AT START UP.....	58
18.8 OPTIONS.....	58
18.9 CONTROL CAPABILITY WITH INTERNAL PUMPS.....	59
18.10 COMMAND AND CONTROL.....	59
18.11 PROTECTIONS.....	59
18.12 PROTECTIONS AGAINST ELECTRICAL POWER LOSS.....	60
18.13 EXTERNAL SUPPLY PORTS.....	60
18.14 MULTIPLE CIRCUIT ISOLATION.....	60
18.15 ANGLE OF ATTACK	60

SECTION 19 – ENCODING ALTIMETER CONNECTION DETAILS.....61

FIG. 6 MPS 35C – ENCODING CONNECTION ELECTRICAL SCHEME.....	61
---	----

PRELIMINARY

This Manual is valid from the SW Version 3.17

Introduction

This manual contains the operating procedures for the MPS 35C air data test set and is suitable for both workshop and flight-line servicing.

Safety

The MPS 35C is designed to be safe when operated in the manner described in this manual, it should be used only in the described way and for no other purposes. The manual contains Safety Instructions that must be followed, the instructions are either warnings or cautions given to protect the Operator and the equipment from damage.

Use trained technicians and good engineering practices for all the procedures in this manual.

Warning

Potentially explosive atmospheres may occur during aircraft refuelling. This equipment is not certified for use within potentially explosive atmospheres. An appropriate risk assessment should be performed when this equipment is to be used on aircraft with particular attention being given to the dangers arising from re-fuelling operations. Within the EU, organisations operating equipment where potentially explosive atmospheres may occur are required to conform to the ATEX 137 Worker Protection Directive, EU 99/92/EC. Contact DMA for details of the ATEX certification standards applicable to the MPS range of products.

Pressure

Never apply pressure greater than the maximum safe working pressure to the equipment.

Toxic Materials

There are no known toxic materials used in the manufacture or build standard of this MPS 35C, except for the rechargeable battery..

Maintenance and Repair

The MPS 35C is to be maintained and repaired using the approved procedures and be carried out only by authorised agencies or the manufacturer.

Information and Advice


Contact the manufacturer, subsidiary or agent for further detailed technical advice.

IMPORTANT NOTES

The manual vent valves on the front panel must be completely closed before the start of testing.

Connect the ADTS to the static and pitot ports only after the start up procedure.

For optimum operation and highest precision, the MPS 35C must be operated with the front panel face up. The internal sensors are slightly position sensitive.



- | | |
|---|--|
| 1. "On/Off" Power Switch | 10. Static Ports (x2) + Static or A.O.A Ports (x2) |
| 1A. Push button (to start with battery power) | 11. Pitot Ports (x4) |
| 2. Fuse | 12. Keyboard |
| 3. Power Connector | 13. LCD Display |
| 4. Pitot Vent needle Valve | 14. Encoding Altimeter Connection (Optional) |
| 5. Cross bleed needle Valve | 15. External vacuum supply port |
| 6. Labyrinth to ambient | 16. External pressure supply port |
| 7. Serial Port | 17. USB Port |
| 8. Hand Held Remote Terminal | 18. Ground Connection |
| 9. Water condensate extraction button | |

FIG. 1 - AIR DATA TEST SET P/N MPS 35C FRONT PANEL




FIG. 2 - LAYOUT OF HHRCU KEYBOARD AND DISPLAY

SECTION 1 - MPS 35C CONTROL KEYS

1.1 GENERAL DESCRIPTION

The D. Marchiori, DMA, MPS 35C is an Air Data Test solution for troubleshooting and certification of aircraft pitot-static systems with RVSM accuracy requirements. It provides the operator with the ability to test the aircraft and to generate and store re-test envelopes required for air data testing of all modern commercial and various military fixed and rotary wing aircraft. Additional to normal pitot-static testers it also has a third delta P read and control channel for the testing of Angle of attack Smart Probes

The MPS 35C utilises precision hi-technology resonant element and silicon bridge pressure transducers to achieve maximum accuracy.

An internal rechargeable battery providing more than 4 hours operation is included.

The MPS 35C is simple and fast to use. The operator interface is easy to learn and understand by both experts and first time users. All testing and troubleshooting with the MPS 35C is performed via an intuitively arranged colour-coded keypad on the front panel. All test information is displayed on a large, easy to read LCD display or alternatively a multifunction remote hand controller.

Commanded and measured test values are simultaneously displayed at all times.

The MPS 35C incorporates the DMA on-demand pumps system utilised on the series of larger MPS air data test sets. The internal vacuum and pressure sources run only if required, to insure longer pump life.

The MPS 35C comes equipped with built-in protection to safeguard the test set and the UUT or instruments under test, no longer the old problem of damaged instruments or air data test sets.

Both the test set and instruments under test are protected by important key MPS 35C design features. The pressure condition of P_s greater than P_t (negative airspeed / Q_c) is prevented in both manual and automatic operation. The Unit Under Test (UUT) is safely isolated in the event of any power loss.

The MPS 35C is designed to reject any commanded values which exceed pre-programmed limits. Limits values are password protected.

To facilitate leak testing and troubleshooting, the MPS is supplied with multiple ports, located on the front panel which can be isolated individually, and can be controlled either by the Hand Held Remote control Unit (HHRCU) or the front panel keyboard. Different static and pitot pressures can also be established in these lines and applied as required.

For Angle of Attack testing these ports are reconfigured to allow testing of P_{s1} - P_{s2}

The MPS 35C allows the User to carry out simple to perform in-house calibrations. Using a transfer calibration standard (for example the D. Marchiori's own product the PAMB 6 or PAMB 7), the MPS 35C can be calibrated in typically less than 20 minutes after a sufficient warm up period.

Calibration is performed by software adjustment only. No mechanical adjustments are required to the ADTS. Calibration factors are password protected.

MPS 35C is with USB port to store and manage test results.

MPS 35C optionally can also be equipped with an encoding altimeter reading function.

1.2 PHYSICAL DESCRIPTION

The MPS 35C main constituents feature of a power supply, digital control cards, pressure sensors, and pneumatic control components. All are packaged within a case of lightweight HDPE material.

The front panel provides operating controls and displays, pressure fittings and electrical connectors for external control.

A picture of the MPS 35C console is displayed in Fig.: 1.

1.3 KEYPAD KEYS

Control and data entry of the MPS 35C is via a keypad on the front panel (Fig. 2). Five rows of keys provide access to all of the MPS 35C's control and operational functions. Keys are colour coded for ease of use. A telephone format 0 to 9 keypad is included for entry of target values.

First Row keys:

HALT: when pressed the MPS 35C remains in the CONTROL MODE but adopts automatically, as the COMMANDED (controlled) air data parameters, the values which are present at the instant the **HALT** key has been pressed.

The **HALT** key can be considered as a "panic button" to be used when it is necessary to hold the parameters at the current values.

LIMITS-UNITS / **EPR** is used to enter the LIMITS/UNITS MENU or EPR MENU. These menus are for viewing or changing the default limit values and units as they are pre-set from the factory. To return to CONTROL MODE of operation, the **LIMITS-UNITS** key must be pressed a second time. Refer to Section 6.

The **EPR** key, in association with the **SHIFT** key, activates the E.P.R. function. Refer to Section 12.12.

EXEC / **PROG**: This key is used to run a particular pre-defined test profile: the MPS 35C can store 30 different test profiles, each one with 26 different test points; the target values of Altitude, Airspeed, Altitude Rate and Airspeed Rate can be entered and stored into each of the 30 test profiles. Refer to Section 14.

The **PROG** key, in association with the **SHIFT** key allows the entering of program profile points

MEM / **CAL**: The **MEM** key is used to memorize new parameters; the **CAL** is used to tare off any pitot sensor minor errors to improve its performance at low airspeeds.

MULTIPLE ISOLATOR / **ENC** is used to select which of the optional multiple isolated Ps and Pt ports are to be opened, or closed. Refer to Section 9.

The **ENC** key, in association with the **SHIFT** key, activates the Encoding Altimeter option. Refer to Section 12.13.

SHIFT has the same function as a shift key on a computer keyboard. It is used together with other keys to command alternate key functions (e.g. **[SHIFT]** + **[LIMITS-UNITS]** to activate E.P.R.), or **[SHIFT]** + **[0]** to activate the "Fine Tuning").

A summary of **SHIFT** key operations is shown in Section 12.15.

BACKSPACE: this key is used to delete the last entered digit if a mistake is made in entering a command.

Second Row Keys, left side:

MEAS: the MEAS or "MEASUREMENT" is used to stop the operation of the pressure control system leaving only the pressure measuring system active. This function is used to achieve extra accuracy for measuring pressures statically to avoid any controller induced effects.

The **CNTRL**, CONTROL key is used to return the MPS 35C to the CONTROL MODE.

VENT: is used to vent the pressure in the static and pitot lines to ambient pressure. This function allows for the safe disconnection of test lines from the aircraft or UUT at the end of testing. The **CNTRL** key is used to restore the MPS 35C to CONTROL MODE, after the Vent function has been selected.

LEAK: is used to automatically perform the leak test using the built in timer/stopwatch function of the MPS 35C. The **CNTRL** key is used to restore the test set to the CONTROL MODE of operation, after **LEAK** key is used.

Second and Third Row Keys, right side:

The UP (DOWN) triangular keys  (or ) are used:

- to increase (or decrease) the different parameters (ALTITUDE, AIRSPEED, RATE OF CHANGE, PRESSURES) by a selected digit value;
- in the UNITS MENU, for the changing of parameters units;
- in programmed profiles to select the next (or previous) test point;
- in the DISPLAY MENU to set the display (brightness and contrast).

The same keys are also used in some other specified operations.

Third Row Keys, left:

CNTRL: is used to initiate or to return the equipment to CONTROL MODE.

NOTE

CNTRL is the most frequently used key in the general operation of the MPS 35 C.



Qc/Pitot: is used to toggle switch between differential pressure (Qc) and pitot pressure.

ALRt/ASPRt: is a toggle switch used to select either ALTITUDE RATE, AIRSPEED RATE, STATIC PRESSURE RATE or PITOT PRESSURE RATE.

The default AIRSPEED RATE value is 300 knots/min. The default ALTITUDE RATE is 3000 Ft/min.

Fourth and Fifth Row Keys, left:

The **DIGIT** key is used to select different digits on each Air Data Parameter.

The  or  keys are used to navigate around the display in the CONTROL, LIMITS and UNITS menus. These keys are used to move the cursor ">" to the desired input zone for entry of a specific value using the numeric keypad.

The **000** key is used to enter thousands into a demand value, if allowed by the programmed limits.

The **ENTER** is used to input desired data the MPS 35C. The operation is the same as an "Enter" key on a computer keyboard.

Numerical keypad, center:

This keypad is a standard telephone layout layout ten-keys keypad. The numerical keys (0–9) are used to enter any desired value of the various controlled parameters. After keying in number values, the **ENTER** key is always required to enter, confirm, the completed number into the system.

NOTE

*For some optional operations, number keys may be used in combination with the **SHIFT** key, to access additional functions.*

The decimal point key (.) is used to input decimal points when required (e.g. airspeed).

The minus key (–) is used to set negative altitudes (e.g. when static pressure is higher than the ambient).

SECTION 2 - OPERATIONAL MODES, MENUS AND DISPLAYS

NOTE

The MPS 35C has multiple operational modes, menus and displays. Modes are defined by the operational characteristics that are in use during operations in the named mode. Menus refer to operations and information that are accessible and changeable on the displayed LCD screen. Displays refer to data that is displayed in a read-only format on the screen. Display screens are read only; they do not allow parameters to be entered or changed.

2.1 CONTROL MODE

This is the primary mode for control of the MPS 35C. Air data parameter entry and all the operational/control functions are all performed in this mode. The access to CONTROL MODE is through the CONTROL MENU.

Entry to the CONTROL MODE is by pressing the **CNTRL** key.

Return to CONTROL MODE at any time from any other mode of operation is by pressing the **CNTRL** key.

2.1.1 CONTROL MODE MENU

The CONTROL MODE MENU is displayed when the MPS 35C is in CONTROL MODE. SIMULATED (ACTUAL) values are displayed on the "SIM" line of the display while the COMMANDED (DESIRED) values are displayed on the "CMD" line of the display.

Air data parameters will be displayed on the upper two lines of the LCD screen (upper "CMD" and "SIM" lines) and the equivalent pressure parameters will be displayed on the lower two lines of the screen (lower "CMD" and "SIM" lines).

2.2 MEASURE MODE

MEASURE MODE is used to stop controlling the pressures so that only the pressure measuring system is activated: all control functions are disabled and only sensor measurement functions are active. The unit under test (UUT) is now completely isolated from the pressure generator and a precise measurement can be obtained when the line pressures in the system under test are stabilized. Whenever a precision measurement is required, in particular when the large volumes are involved, the MEAS function should be used. MEASUREMENT MODE can be accessed from all menus.

Entry to the MEASUREMENT MODE is by pressing the **MEAS** key.

Return to CONTROL MODE is by pressing the **CNTRL** key or to other modes by pressing the required mode entry key.

2.2.1 MEASURE MODE MENU

The MEASURE MODE MENU is displayed when the MPS 35C is in MEASURE MODE. When the MEASURE MODE MENU is displayed, the word "MEAS" will appear in the lower right-hand corner of the LCD screen.

2.3 VENT MODE

This mode is used to vent the pitot and static ports of the MPS 35C to the current ambient, or ground, pressure condition. The VENT MODE operates by pressing the **VENT** key.

- If the venting operation is the first after switching on, MPS 35C sets itself to a conventional altitude value (- 9.900 feet); however the altitude value decies only to the value corresponding to ambient pressure: the warning:"AMBIENT PRESSURE REACHED" is now displayed.
- In all other situation, the MPS 35C automatically initiates a 3000 feet/min. descent (or ascent) rate to reach initially an altitude 2000 feet higher than local Field Elevation. When the MPS 35C reaches this 2000 ft value higher than local Field Elevation, it then pauses the venting to measure the actual current ambient pressure value and then continues the venting bringing the Ps and Pt ports to that safe pressure. This ensures the pressures inside the hoses are identical to the ambient pressure and the aircraft or system under test can safely be disconnected

In the MPS 35C it is possible to set the field/location value, and then to read the QNH.

When the instrument is shipped a value of zero feet will be entered as the Field Elevation. To set a different value of the Field Elevation, follow the instructions contained in the Calibration and Adjustments Manual.

When the conditions are safe to disconnect the hoses, the legend:
"AMBIENT PRESSURE REACHED" is displayed.

Entry to the VENT MODE is by pressing the **VENT** key.

From VENT MODE, only the CONTROL MODE can be accessed.

To return to CONTROL MODE press the **CNTRL** key.

VENT MODE MENU

The VENT MODE MENU is displayed when the MPS 35C is in the VENT MODE. When the VENT MODE MENU is displayed, the word "VENT" will appear in the lower right-hand corner of the LCD screen.

2.4 LEAK MODE

The LEAK MODE initiates the automatic leak test and stopwatch measurement feature of the MPS 35C. LEAK MODE access is through the LEAK MENU.

Entry to the LEAK MODE is by pressing the **LEAK** key.

Return to CONTROL MODE is by pressing the **CNTRL** key.

2.4.1 LEAK MODE DISPLAY

The LEAK MODE DISPLAY is shown when the MPS 35C is in LEAK MODE. When the LEAK MODE is in operation, ALTITUDE RATE ("AltRate") and AIRSPEED RATE ("Asp Rate") plus elapsed time in seconds will be displayed on the upper two lines of the LCD screen. The legend "LEAK" appears in the lower right-hand corner of the LCD screen.

2.5 LIMITS MODE

The LIMITS MODE allows the operator to change the actual limits of all the functions. Access to the LIMITS MODE is via the LIMITS MENU.

The **LIMITS** key is used to enter LIMITS MENU. To return to CONTROL MODE or any other mode, the **LIMITS** key must be pressed a second time.

2.5.1 LIMITS MODE MENU

The LIMITS MODE MENU is displayed when the MPS 35C is in LIMITS MODE. When the LIMITS MODE MENU is displayed, two vertical columns of parameters will be shown, starting with the parameter "AlMx >". Refer to Section 6.

SECTION 3 - START UP PROCEDURE

Place the MPS 35C with the panel face up.

Connect the power cord to the military style connector on the front panel. Ensure that the ground is connected, if necessary utilise the ground post on the front panel if the ac lead itself is not grounded.

Leave the static and pitot lines disconnected. Static and pitot lines should be connected only after start-up is complete.

Turn the power toggle switch to "ON". The supply indicator lamp will illuminate if ac power is present at the test set.

WARNING

- If MPS 35C is not power connected or the ac power is not available, it can operate with the internal battery power. In this situation, after turning on the toggle switch to "ON" (Fig. 1-1), additionally press the green push button (Fig. 1, 1-1A).
- The battery is being charged only when the MPS 35C is power connected and the switch (Fig. 1-1) is in up or down position.

When the start-up and self-test is completed, there are two possibilities:

- A. If an altitude higher than 2000 ft + local Field Elevation is sensed in the static line, the MPS 35C automatically continues in the control mode and allows the Operator to either continue working at that altitude, or to press the **VENT** key to vent the MPS 35C.
- B. If the altitude is lower than 2000 feet plus local Field Elevation value, the equipment will start a VALVES TEST, which is shown in the display right lower corner with the word "WAIT". Once this valves self exercising routine has been completed the equipment will then read the ambient pressure and will vent the system to this value. The valves self exercising routine ensures optimum control valve operation, and runs for approximately 5/6 minutes, it can be terminated at any time by pressing the **HALT** key.

To vent the MPS 35C, press the **VENT** key. The MPS 35C sets itself to a conventional altitude value (- 9.900 feet); however the altitude value decies only to the value corresponding to ambient pressure: the warning: "AMBIENT PRESSURE REACHED" is now displayed. Press **CNTRL** key to then initiate in CONTROL MODE.

If this initial venting to ambient conditions is not completed the reason can be that the local Field Elevation has not been set, see the instructions outlined below.

WARNING

Any time the MPS 35C is switched on, it is *necessary* to complete the "venting operation" until the ambient pressure is reached and the display shows "AMBIENT PRESSURE REACHED"; if this operation is not completed, during the test the ADTS won't be able to reach pressure values below the ambient one.

IMPORTANT NOTE FOR THE FIRST TIME USE IN A GIVEN LOCATION

It is recommended that the operator enters the Field Elevation of the location where the MPS 35C is being to be used, to permanently save this value in the internal memory. It is very important during the VENTING MODE of operation: when venting to the ambient pressure the MPS 35C will measure the ambient pressure when at a value that is 2000 feet higher than the Field Elevation.

To set and permanently memorize the correct Field Elevation value, follow the instructions given in the Calibration and Adjustments Manual.

*If at the first start-up the Venting Operation it is not performed fully, press **CNTRL** key to enter the OPERATIVE MENU and proceed to set and memorize the Field Elevation Altitude as per Calibration and Adjustment Manual.*

SECTION 4 - ENTERING AIR DATA TEST PARAMETERS INFORMATION

Air Data Parameters (ALTITUDE, AIRSPEED and RATE) can be commanded (entered) in two modes:

1. By operating the MPS 35C in the CONTROL MODE.
When the CONTROL MODE is active the MPS 35C starts to change the pressures as soon as new air data values are entered.
2. By operating the MPS 35C in MEASURE MODE.
If it is desired that the MPS 35C starts to change pressures only after all the new air data parameters have been entered, it is necessary to go to the MEASURE (or HALT MODE), enter the new target values and then return to the CONTROL MODE by pressing the **CNTRL** key.

New target values can also be entered by using the **▲** (to increase) or **▼** (to decrease) triangle keys.

NOTE

*If a value of ALTITUDE or AIRSPEED or ALTITUDE RATE greater than the actual limits (the values programmed in the LIMITS MENU) is selected, the value will not be accepted and the limit value automatically will be entered instead. As an example, if an airspeed value of 999 knots is entered while the limit value is set at 400 knots, 400 knots will be the commanded value into the equipment, when the **ENTER** key is pressed.*

4.1 METHOD 1, ENTERING OF SPECIFIC COMMAND VALUES

The MPS 35C is programmed by entering COMMAND ("CMD") line values for ALTITUDE, AIRSPEED and RATE OF CHANGE in the CONTROL MODE. A COMMAND value may be entered in any of the COMMAND LINE input zones after selecting ALTITUDE, AIRSPEED or RATE. To enter a COMMAND value, the cursor (>) must be in the desired input zone. Arrow keys (**←** or **→**) are used to navigate the cursor (>) to the desired input zone. The arrow keys can be used at any time when the MPS 35C is in CONTROL, HALT or MEASURE MODE.

These arrow keys (**←** or **→**) are used to move among each of the three parameter columns (ALTITUDE, AIRSPEED and RATE) and also to move up and down on the three display screen parameter columns (the ALTITUDE column, AIRSPEED column and RATE column).

By pressing the right or left arrow keys the cursor (>) navigates among the three parameter columns on the upper air data COMMAND ("CMD") LINE (ALTITUDE, AIRSPEED and RATE) and the lower COMMAND LINE for the pressure engineering units.

4.1.1 ALTITUDE COMMAND

To enter an altitude, scroll the cursor to "ALTITUDE" in the COMMAND ("CMD") LINE input zone. Enter the target value by digitizing it on the keypad (20000 feet, for example). If an incorrect number is selected, the **BACKSPACE** key can be used to erase the incorrect digit. After the number is erased with the **BACKSPACE** key, the correct number can be entered. When the correct ALTITUDE has been digitized, press the **ENTER** key to activate the new command value.

4.1.2 AIRSPEED COMMAND

Scroll the cursor to "AIRSPEED" in the COMMAND ("CMD") LINE input zone. Enter the target value by digitizing it on the keypad (400 knots for example). If an incorrect number is selected, the **BACKSPACE** key can be used to erase the incorrect digit. When the correct AIRSPEED has been digitized, press the **ENTER** key to activate the new command value.

4.1.3 ALTITUDE RATE COMMAND (RATE OF CHANGE)

Scroll the cursor to " RATE " in the COMMAND ("CMD") LINE input zone. Enter the target value by digitizing it on the keypad (3000 ft/min. for example). If an incorrect number is selected, the **BACKSPACE** key can be used to erase the incorrect digit. When the correct RATE has been digitized, press the **ENTER** key to activate the new command value.

The MPS 35C will begin to achieve the entered COMMAND LINE value immediately. When it is preferable that the MPS 35C should start to reach the values only after all the new parameters have been properly entered, then enter the commanded parameters in the MEASURE MODE; in this case it is also then necessary to re-enter into the CONTROL MODE by pressing the **CNTRL** key and all the new values will then be activated.

	ALTITUDE	AIRSPEED	RATE	
SIM	24519	192.8	3000	SIM
CMD	30000	200.0	3000	CMD
SIM	11.338	1.817	0,465	SIM
CMD	8.885	1.959	CNTR	CMD
	Pst	Qc/Ptot	MACH	

FIG. 3 - EXAMPLE OF DISPLAY LAYOUT IN CONTROL MODE

In CONTROL MODE the MPS 35C operates so that the simulated values of altitude are reached in the pressure line and stabilized. MPS 35C can also compensate possible leak in the static line: the presence of the leak is warned by an * adjacent to CNT symbol, as in the below example:



	ALTITUDE	AIRSPEED	RATE	
SIM	24519	192.8	3000	SIM
CMD	30000	200.0	3000	CMD
SIM	11.338	1.817	0,465	SIM
CMD	8.885	1.959	CNT *	CMD
	Pst	Qc/Ptot	MACH	

4.2 METHOD 2-VALUES COMMAND WITH DIGIT CHANGE FUNCTION

Air Data Parameter values can also be modified by using the "Digit" function. As with the direct value entry method above, the "Digit" function can be used in CONTROL or in MEASURE MODE.





The "Digit" function provides a quick way to change an Air Data Parameter.

The UP (DOWN) triangle keys  (or ) and **DIGIT** key are used with the "Digit" function. Once selected with **<** or **>** keys, each Air Data Parameter has one digit flashing.

Use  (or ) keys to increase or decrease the flashing digit by 1.

Use **DIGIT** key to move to the left (or **SHIFT DIGIT** keys to move to the right) to change the parameter digit that is to be changed.

For example: Altitude parameter is selected, and the set value is 6543:

- if 6 is the flashing digit, pushing  (or ) keys the set Altitude can be modified to 7543, 8543.... (increasing), or to 5543, 4543... (decreasing);
- use **DIGIT** key (or **SHIFT DIGIT** keys) until the another digit starts flashing, for example the last one (3); now pushing  (or ) keys the set Altitude can be modified to 6544, 6545 increasing), or to 6542, 6541 (decreasing).

The "Digit" function can increase (or decrease) the value of a parameter in units, tens or hundreds 1,10,100 ... depending on the flashing digit.

As described, using the "Digit" function, once an Air data parameter is selected, any digit can be modified separately from the others.

A continuous increase (decrease) of the parameter is obtained when  (or ) keys are maintained pressed.

4.3 ACOUSTIC ALARM FUNCTION

When the SIM (Actual) values are almost at the CMD (Desired) values (around 10 feet and 1 knot) an acoustic alarm will start sounding (beep-beep) to warn the operator that the MPS 35C is approaching the target values.

If the operator does not want the acoustic signal, the function can be deactivated by the key **(SHIFT 0) = F0**, followed by password. Refer to Section 12.14.

SECTION 5 - ADVANCED OPERATIONS

5.1 DIFFERENT RATE COMMANDS

The **ALRT/ASPR** key is used to select the different rates.

Below the word "RATE" a letter in front of the numerical value will indicate the active function: i.e. the letter "A" will indicate to the operator that the rate controlled is the ALTITUDE RATE. The Altitude Rate is the default.

By pressing the **ALRT/ASPR** key, the letter "S" will appear in front of the value shown on the display meaning that the equipment is now controlling the AIRSPEED RATE.

Note that the equipment has an AIRSPEED RATE default value of 300 Kts/min.

By pressing the key code **SHIFT • 5 6 7 8**, the rates are now able to be entered in pressure units (STATIC and DIFFERENTIAL PRESSURE RATES instead of ALTITUDE and AIRSPEED RATES). Press again **SHIFT • 5 6 7 8** keys to return to engineering units (ALTITUDE and AIRSPEED RATES).

Summarizing, by pressing the **ALRT/ASPR** key, the operator can select alternatively the Altitude Rate or the Airspeed Rate, and the Static Pressure Rate or the Differential Pressure Rate, in the engineering unit which has already been selected: the active parameter will always be shown in front of the word "RATE" on the screen (SIM line).

*For safety reasons, when passing from engineering units to pressure units, the MPS 35C remains in the CONTROL MODE, but adopts automatically, as the COMMANDED (controlled) air data parameters, the equivalent values of altitude and airspeed which are present at the instant the **SHIFT • 5 6 7 8** keys have been pressed.*

CAUTION

If MPS 35C is switched off, then when it is next powered up, the default rates will be ALTITUDE and AIRSPEED RATES.

To permanently store pressure units (STATIC and DIFFERENTIAL PRESSURE RATES) instead of ALTITUDE and AIRSPEED RATES as "default rates" in the MPS 35C consult the MPS 35C Calibration and Adjustment Manual where instructions to achieve this modification are given.

5.2 PRESSURE VALUES COMMAND IN DIRECT ENGINEERING UNITS

If desired, instead of aeronautical units, direct pressure units can be used to enter pitot or static pressure values or differential pressure values (pitot pressure – static pressure). For this operation, the lower COMMAND ("CMD") LINE input zones are used. The commanded default pressure value is displayed in inches of Mercury or inHg.

5.2.1 ALTITUDE COMMAND USING DIRECT PRESSURE VALUES

Scroll the cursor to the lower COMMAND LINE input zone for Pst (Static Pressure). The desired pressure value can be entered by using a direct number value or by using the **▲** (or **▼**) keys.

Enter the desired specific pressure value by digitising it on the keypad (18.00 inHg for example).

If an incorrect number is input, the **BACKSPACE** key can be used to erase the incorrect digit.

After the incorrect number has been erased with the **BACKSPACE** key, the correct number can be entered. When the correct Ps is entered, press the **ENTER** key to confirm the new value.

5.2.2 AIRSPEED COMMAND USING DIFFERENTIAL PRESSURE VALUES

(Qc = Differential Pressure)

Scroll the arrow prompt to the COMMAND ("CMD") LINE input zone for Qc (Differential Pressure). The desired pressure value can be entered by using a direct number value or by using the Δ (or ∇) keys.

Enter the desired specific pressure value by digitising it on the keypad (10,55 inHg for example). If an incorrect number is entered, the BACKSPACE key can be used to erase the incorrect digit. After the incorrect number has been erased with the BACKSPACE key, the correct number can be entered. When the correct Qc is entered, press the ENTER key to confirm the new value.

5.3 SPECIFIC PITOT PRESSURE VALUE COMMAND

To enter a specific pitot pressure, use the Qc/Ptot key ("Qc" for differential pressure and "Ptot" for Pitot pressure. [= Static pressure + Differential Pressure]).

Qc/Ptot key is used to toggle between the normal default setting (Qc) Differential Pressure and the Pitot total Pressure (Ptot).

The value displayed in the COMMAND ("CMD") LINE input zone will toggle between DIFFERENTIAL PRESSURE (Qc) and PITOT TOTAL PRESSURE (Ptot).

The Qc/Ptot key should be used to toggle from one to the other, on the screen the DIFFERENTIAL PRESSURE value or the PITOT PRESSURE (Ptot) one will appear.

Enter the desired PITOT PRESSURE (Ptot) or the DIFFERENTIAL PRESSURE (Qc) value in the input zone and press the ENTER key to confirm the new value.

5.4 MACH NUMBER

MACH NUMBER can be entered as a control parameter in place of an AIRSPEED value. To enter a MACH NUMBER select the MACH NUMBER value in the COMMAND MENU. After inputting the desired MACH NUMBER, press ENTER. The AIRSPEED corresponding to this Mach number, at the set altitude, will now be shown in the CMD line of the AIRSPEED column. Note that MACH NUMBERS are altitude dependent.

If another Mach Number at a different altitude has to be entered, the same procedure must be followed. This is because the Mach number is only calculated for a particular ALTITUDE and set as the target AIRSPEED for that ALTITUDE.

MACH NUMBER must be entered when the Altitude Rate is not equal to 0.

5.5 LEAK TEST MODE OPERATION

The LEAK TEST MODE operation allows the operator to perform a leak test of the static and pitot lines by using the internal stopwatch. Leak rates for pitot and static lines are calculated every second and are automatically shown in ft/min. and kt/min. in the LEAK MODE DISPLAY screen.

Warning

It is recommended that an initial leak test is always carried out at low altitude and low airspeed values in case there are dramatically large leaks which could cause problems if not corrected.

Select the leak test function by pressing the LEAK key. The LEAK DISPLAY will appear. The LEAK DISPLAY will begin counting the elapsed seconds and displaying the leak rates for the pitot and static lines, below the Alt + Asp rates.

	ALTITUDE	AIRSPEED	RATE	
SIM	sec	AltRate	AspRate	SIM
CMD	170	-6	0.4	CMD
SIM	20.593	0.504	0.189	SIM
CMD	28.577	0.481	LEAK	CMD
	Pst	Qc/Ptot	MACH	

WARNING

After the **LEAK** key has been pressed, in order to to get the best LEAK measurement ,it is necessary to wait until the values in the LEAK DISPLAY are relatively stable.

Typically this happens after about one minute.

When the leak values are stabilised, press the **LEAK** key once more to reset the clock to restart a further leak test.

To return to the previous menu, press the **CNTRL** key.

5.6 MEASURE (MEAS) MODE

The **MEAS** key commands the MPS 35C to the MEASUREMENT MODE of operation. In this mode the MPS 35C deactivates the pressure control circuit and only the pressure measuring system remains activated. The unit under test is completely isolated from the pressure generator circuits of the MPS 35C. A very precise measurement can be taken once the pressures in the lines under test are stable. This mode should be used whenever very precise measurement is required.

The MEASURE MODE function should always be used when very large test volumes are involved in the measurement, such as with an older aircraft. To return to CONTROL MODE, press the **CNTRL** key.

CAUTION

When the MPS 35C is in MEASURE MODE or in LEAK MODE of operation and a leak higher then a prefixed value (i. e. 3.000 feet/min.) is in progress, the equipment will revert automatically to the CONTROL MODE as a protection of the UUT.

To permanently store a different value as default in the MPS 35C memory, consult the MPS 35C Calibration and Adjustment Manual where instructions to achieve this modification are given.

SECTION 6 - PRESET LIMITS AND ENGINEERING UNITS CHANGE

6.1 CHANGING PRESET LIMITS

CAUTION

Limits are pre-set at the factory to handle most standard test conditions and to protect most aircraft instrumentation. The operator should use extreme care and caution when setting limits different to the factory default values. Damage to the aircraft or unit under test could occur, if caution is not observed.

To enter the LIMITS MENU from the CONTROL MENU use the **LIMITS** key.

To exit the LIMITS MENU press again the **LIMITS** key. Arrow keys (**▲** **▼**) are used to navigate the enter cursor (>) to the desired input zone.

CAUTION

The LIMIT MENU allows the operator to change either the operative limits and/or the Engineering Units of MPS 35C. The first three rows of the menu are dedicated to the change of operational limits, the last one to modify the Engineering Units.

Limit values can be changed either permanently or for the duration of one test cycle. The operator should consider carefully which requirement best suites the needs of all users.

To change the limits or the step values, scroll the cursor to the front of the value of the limit that is to be changed.

To change the value, enter the new value and press the **ENTER** key.

The pre-set limits are given in the LIMITS MENU as follows:

- ALMx is the maximum allowed altitude.
- ALMi is the minimum allowed altitude.
- ASMx is the maximum allowed airspeed.
- MaMx is the maximum allowed Mach number.
- AltRateMx is the maximum allowed altitude/rate.

NOTE

If different Rates have been selected in the CONTROL MENU (Refer to Par. 5.1), different rate limits are displayed in the menu, instead of AltRateMx :

AirSpRateMx to set the maximum allowed Airspeed Rates

PrStRateMx to set the maximum allowed static Pressure change Rate

PrQcRateMx to set the maximum allowed Differential Pressure Rate.

When all required limit changes are entered or custom step functions are set, exit from the LIMITS MENU as above.

Pressing the **LIMITS** key memorises the new limits and returns the MPS 35C to the CONTROL MODE and to the CONTROL MENU. All future operations will automatically utilise the new limits until power is turned off, or the limits are changed again. When the MPS 35C is next powered up, the default limit values will be the active ones.

6.2 PERMANENT MEMORISATION OF LIMITS

To permanently memorise new limit or step values in non-volatile memory, consult the MPS 35C Calibration and Adjustment Manual where instructions to achieve this modification are given.

6.3 ENGINEERING UNITS CHANGING

Alternative Engineering units can be selected.

Access to the UNITS MENU is from the COMMAND MENU. While in the COMMAND MENU, press the **LIMITS** key. The menu for selecting new Engineering Units (UNITS MENU) is located in the last row of LIMIT MENU.

Options are as follows:

Default	Engineering Units	Option
Altitude	Ft (feet)	mt (meters), hm (hectometers)
Airspeed	Kt (knots)	Kh (kilometers per hour), Mh (miles per hour)
Pressure	in (inches Hg)	hp (hectoPascal or mbar) Pa (Pascal) Kpa (KiloPascal) pi (pounds per square inch), mm (millimeters Hg)

Use the **<** or **>** keys to scroll the cursor ">" in front of the parameter for which the Engineering Unit should be changed. For example, if it is desired to change the Engineering Unit for the AIRSPEED parameter, scroll the cursor in front of the "Kt" symbol (for knots).

To change "Kt" to "Mh" (miles per hour) use the **▲** key. To revert back to knots, press the **▼** key.

After the required engineering units has been properly selected, press **LIMITS** key once more to return to CONTROL MODE.

It is possible to return to the CONTROL MODE also by pressing the **CNTRL** key.

To permanently store new measure units as default in the MPS 35C memory, consult the MPS 35C Calibration and Adjustment Manual where instructions to achieve this modification are given.

6.4 ALTITUDE AND AIRSPEED RATE ENGINEERING UNITS CHANGE

Rates are normally indicated in altitude/time and airspeed/time.

Time Engineering Units are:

- Minutes for feet, knots and pressure units (but Pa).
- Seconds for mt and hm and Pa.
- Hours for Kilometers and Miles

SECTION 7- ULTRA LOW SPEED FUNCTION

(Dynamic Pressure, Qc, Zero Adjusting)

For a very low AIRSPEED measurement, it is recommended that the MPS 35C differential (dynamic Qc) pressure should be zeroed any time a new test sequence is to be carried out. The zeroing of Differential Pressure will give the best accuracy for the AIRSPEED channel at Low Airspeed.

The ALTITUDE channel of the MPS 35C is not affected.

The zeroing is done by setting the differential pressure (pitot line pressure minus the static line pressure) to zero at the ambient pressure.

The CAL (SHIFT MEM) key can be used to adjust the zero dynamic pressure.

To correct zero dynamic transducer shift, set the demanded Airspeed = 0 and Altitude = ambient value; wait until the set values are reached and stabilised. Then press the CAL (SHIFT MEM) key twice.

This zeroing function, useful for high precision, low Airspeed testing, must be used with the Altitude values near to ambient pressure.

If the zero error is too large, the zero correction with CAL (SHIFT MEM) key will not be permitted: in this case it is necessary to carry out a new calibration: refer to the Calibration and Adjustments Manual.

SECTION 8 - INTERNAL BATTERY

MPS 35C is equipped with an internal rechargeable battery.

The master power switch (Fig. 1-1) has 3 positions instead of the normal 2 (On/Off):

- Up position (On): MPS 35C is switched on and runs with battery power (if MPS 35C is connected to the power line, the battery is charged while the equipment is operating)
- Middle position: MPS 35C is switched off;
- Down position (Off): MPS 35C is switched off, but, if connected to the power line, the battery is charged. Re-charge time in this position is approx. 2 hours for full charge.
- Note that while charging the battery status will indicate in excess of 100% charge

It is possible to check the battery charge status by pressing the (SHIFT 3) key; then the HALT key to return to main menu. If the battery reaches a lower than safe level, the display signals – at regular intervals – the reduced life (this function is not operating when the equipment is running test profiles).

Note that if the battery is low, the display will continue to flash a message “BATTERY LOW” and will then permit a further 10 minutes (approx) operation before automatically switching off the MPS 35C.

If the battery is lower than a minimum level, the MPS 35C automatically switches off. Connecting the apparatus to an a.c. power line allows the operator to continue the test.

SECTION 9 - MULTIPLE ISOLATOR

The MPS 35C is equipped with Multiple Isolators

With the Multiple Isolators it is possible to execute the leak test independently for 4 static lines and 4 pitot lines

Connect the required static and pitot outputs to the static and pitot lines of the aircraft, and leave the other lines closed.

During normal functioning, the multiple isolator internal solenoid valves are normally open.

Press **MULTIPLE ISOLATOR** to activate the Multiple Isolators. The system then enters into the Leak Mode.

The display shows a menu similar to leak test menu, and 8 symbols in the lower line:

an "=" indicates an open valve, an "x" indicates a closed valve.

The position, starting from the left of the "=" or the "x," shows the condition of the relevant valve. (digits 1, 2, 3, 4 refers to 1,2,3,4 static ports, 5, 6, 7, 8 refers to 5,6,7,8 pitot ports).

Press the digits (1, or 2,.../. 8) related to the static and pitot ports on the front panel to open (or close) the corresponding static and pitot valves.

Alternatively, pressing the same digit opens and closes the same valve.

Press 0 to open all the valves. Press 9 to close all the valves.

Press the **ENTER** key to restart the timing of the leak rate.

To return to the CONTROL MODE (all valves open), press **HALT** or **CNTRL** key.

CAUTION

A test at low altitude and airspeed is recommended initially to check for very large leaks. Correct the large leaks before proceeding

As mentioned in Section 5.- 5 and 6, when the MPS 35C is in MEASURE MODE or in LEAK MODE of operation and a leak higher than a prefixed value (i.e. 3.000 feet/min.) is detected, the equipment will revert automatically to the CONTROL MODE as protection for the UUT.

SECTION 10 - ANGLE OF ATTACK OPTION

10.1 GENERAL

The ADTS MPS 35C can set the Angle Of Attack (A.O.A.) parameters, either by the direct angle setting in degrees, or setting values in the corresponding pressure units.

The connection between angle and pressure is linear: the operator – with a password – can enter a special menu, which allows modification of the offset and gain between angle and pressure, as explained here below.

If the operator does not intend to execute tests on A.O.A. (Angle Of Attack) the MPS 35C Multiple Isolator with 4 static and 4 pitot ports is used as already explained in the previous Section 9.

If the operator does want to execute tests on A.O.A., the MPS 35C has a special feature by means of dedicated menus directly from the keyboard.

In this mode, please note that the static ports numbers 3 and 4 on the Multiple Isolator – marked on the front panel with “A.O.A.” identifier – are now used for connection to the A.O.A. adaptors, while ports numbers 1 and 2 remain available for the static connection.

10.2 CONNECTIONS FOR A.O.A. TEST

For A.O.A. testing proceed as below:


- vent the apparatus and bring all pneumatic pressures to ambient;
- disconnect static ports numbers 3 and 4; these ports will now be used only as connections to the pneumatic A.O.A. adaptors;
- use ports numbers 1, 2, as above, as connections to the static pneumatic adaptors
- use ports numbers 3, 4 as connections to the pneumatic A.O.A. Adaptors;
- use ports numbers 5, 6, 7 and 8 as connections to the pitot pneumatic adaptors.

10.3 AIR DATA AND A.O.A. SETTING

To set standard air data (altitude, speed, rates, etc.) and operate in the normal CONTROL MENU, navigate the cursor (>) to the desired input zone and insert the new values, confirming with the **ENTER** key, all as described earlier.

To set the equipment to A.O.A. mode of operation, proceed as follows:

In CONTROL MENU press the **SHIFT** - (shift and negative) keys; the following menu will appear:



It is possible to select from three display configurations: 0, and 1, and 2.

To scroll to the desired menu use the **▲** (or **▼**) keys and then press **ENTER** when the required configuration (0, or 1, or 2) is reached.

The 0 number is the menu for using the test set as a traditional Air Data Test Set, (i.e.: two pressures - Static and Pitot - are displayed and controlled).

The 1 or 2 numbers must be selected to use the MPS 35C to generate the A.O.A. MODE.

10.4 A.O.A. MENUS

10.4.1 ALTERNATIVE A.O.A. MENU 1

WARNING

From now on, the CONTROL MENU Section, normally used to show set data (CMD line) and read data (SIM line) regarding Static, or Pitot, Pressure, will instead be used to show also A.O.A. data. The MACH SIM and CMD values continue to be displayed as in the normal MENU 0

WARNING

This menu is different from the standard one, as it shows a small "p" (pressure) or "a" (angle) before read values of A.O.A. SIMulated. The last line of AIRSPEED column is dedicated to COMmand the A.O.A. values.

The display will appear as the following example:

	ALTITUDE	AIRSPEED	RATE	
SIM	188	120.0	A 0	SIM
CMD	188	120.0	3000	CMD
SIM	29.720	P 0.450	0.182	SIM
CMD	29.720	> 0.450	0.182	CMD
	Pst	Qc/Ptot	MACH	

Set the differential pressure corresponding to the A.O.A. required, inserting the differential pressures values and confirmed with the **ENTER** key, or alternatively modifying the existing values with the DIGIT function.

The value of differential pressure can be set with various measuring units:

- inch. Hg
- hecto Pascal
- p.s.i.
- mm. Hg

WARNING

The maximum value of A.O.A. differential pressures versus. static pressure is limited, by default, to +/- 2,510 inHg or +/- 63,8 mmHg.

WARNING

In the A.O.A. MODE, to set a negative pressure, use the - key before the numeric value, or the DIGIT function to decrease values.

WARNING

If the **HALT** key is pressed in the A.O.A. MODE, the MPS 35C remains in the CONTROL MODE but enters automatically, as COMMANDED (controlled) values of STATIC and DYNAMIC PRESSURES, the values which are present at the instant the **HALT** key has been pressed; at the same time the COMMANDED value of A.O.A. is set = 0.

When values in degrees are required instead of differential pressures, press **Qc/Ptot**: a new menu is then available, similar to the previous one, but a small "a" (angle) will appear before the read value. It is possible to set, by default, angular values between plus and minus 88.6 degrees.

In this mode the display will appear as in the following example:

	ALTITUDE	AIRSPEED	RATE	
SIM	188	120.0	A 0	SIM
CMD	188	120.0	3000	CMD
SIM	29.720	a 0.360	0.182	SIM
CMD	29.720	> 0.360	0.182	CMD
	Pst	Qc/Ptot	MACH	

Hence the **Qc/Ptot** is a toggle key switch on the ALTERNATIVE CONTROL MENU 1 with A.O.A. option changing from differential pressures, "p", to angle of attack, "a".

The relationship between "p" and "a" is set to a specific aircraft when shipped. The User can redefine the relationship to meet new requirements.

The main functions/options already on the CONTROL MENU remain available: it is possible to change other air data (except – of course – the dynamic or pitot pressure), to change the measure units or the limits (with the **LIMITS** key), to carry out leak tests (with the **LEAK** key), or other variables via the (**SHIFT** 0 + Code).

The **VENT** key can also be used to vent all the pressure lines.

By pressing the **LEAK** key it is possible to check the leakages only on static (ST1) and A.O.A (ST2) lines (expressed in pressure measurement units/min.).

The LEAK MENU will appear as in the following example:

	ALTITUDE	AIRSPEED	RATE	
SIM	Sec.	ST1Rate	ST2Rate	SIM
CMD	10	0.001	0.001	CMD
SIM	29.720	P 0.120	0.000	SIM
CMD	29.720	> 0.120	LEAK	CMD
	Pst	Qc/Ptot	MACH	

The first two lines, ST1 and ST2 refer to Static, ST1 and A.O.A.ST2, leakages, the other two lines remain the same as the previous menu.

If required, after the above, select **CNTRL** and the **MULTIPLE ISOLATOR** key activates the check of losses on the Multiple Isolator. With the "A.O.A" option it is possible to check only the

static and A.O.A losses (expressed in pressure measurement units/min.). The MENU will appear as the following example:

	ALTITUDE	AIRSPEED	RATE	
SIM	Sec.	ST1Rate	ST2Rate	SIM
CMD	10	0.001	0.001	CMD
SIM	29.720	P 0.120	0.000	SIM
CMD	= = = =			CMD
	Pst	Qc/Ptot	MACH	

On the keypad 1, 2, can open or close static ports 1, 2,; keys 3 and 4 can open or close A.O.A. ports. Pitot losses on ports 5, 6, 7, 8 are no longer available on this display.

Press 0 to open all the valves. Press 9 to close all the valves.

Press the **ENTER** key to restart the timer for a further leakage test.

To return to the ALTERNATIVE CONTROL MENU 1 (all valves open), press the **CNTRL** key.

To view and modify the dynamic or pitot pressure, while the A.O.A. is set, press the **SHIFT** and - keys on the ALTERNATIVE CONTROL MENU 1, select the 0 menu: the display will not now show the Angle of Attack even though the MPS 35C will hold the last commanded Angle of Attack value; this means that the Angle of Attack value will not return to zero when the Angle of Attack is no longer displayed, but it must first be commanded if required. When viewing with **Qc/Ptot** key the dynamic or pitot pressure, the asterisk symbol "*" in front of the simulated differential or total pressure will remind to the operator that the last commanded Angle of Attack is still controlled.

For zeroing the A.O.A. Value, press **SHIFT** and - keys to enter the ALTERNATIVE CONTROL MENU 1, and set to zero the differential pressure of A.O.A. Then wait until the zero operation is completed.

Now, returning to the CONTROL MENU the asterisk "*" no longer appears in front of the simulated pitot or dynamic pressure. At this point the ADTS has again ports numbers 3 and 4 available for further connections to the aircraft static adaptors, if required.

10.4.2 ALTERNATIVE A.O.A. MENU 2

WARNING

This menu is totally different from the standard one.

WARNING

With this menu is possible to set Pitot Pressure (Pt) < Static Pressure

The display will appear as in the following example:

	ALTITUDE	AIRSPEED	RATE	
SIM	Ps1	29.720	29.720	SIM
CMD	Pd2	29.720	29.720	CMD
SIM	Pt	29.720	29.720	SIM
CMD	RtMx 4.0	A.O.A. [in]	CNTR	CMD
	Pst	Qc/Ptot	MACH	

where:

Ps1 refers to Static Pressure

Pd2 refers to the Differential Pressure of A.O.A.
or **Ps2** to A.O.A. Pressure. (via the **Qc/Ptot** key)

Pt refers to the Pitot Pressure.

RtMx refers to the max. Rate of Pressure change for A.O.A.

A.O.A. [in] indicates that A.O.A is operative and defines the selected pressure measurement unit.

Two value columns are shown in the display: the left column refers to the target values; the right column refers to the actual value.

Note

It is possible to change from **Pd2** to **Ps2** by pressing the **Qc/Ptot** key

CAUTION

Take care, because it is possible to set a value of **Pitot Pressure** less than **Static Pressure**.

Pt can be modified independently of **Ps1**; however, the set difference between the **Pt** and **Ps1** pressures remains the same each time **Ps1** pressure is modified.

NOTE

RtMx refers to A.O.A. max .Rate of change. The Rate of change for **Ps1** and **Pt** are those set on the **CONTROL MODE MENU 0**. (e.g. if in the **CONTROL MODE MENU 0** the rate of Static Pressure is = 0, in the **ALTERNATIVE MENU 2** the **Ps1** cannot be increased or decreased).

WARNING

For security reasons, the **MPS 35C** does not allow the Operator to exit from the **ALTERNATIVE MENU 2** of operation, until **Pt > Ps1**; other control menus are available only when **Pt > Ps1**.

The main functions/options already described on the **CONTROL MENU** remain available: it is possible to change the measure units or the limits via the (**LIMITS** key), or to change other variables via the (**SHIFT 0 + Code**), and vent the pressures lines via the (**VENT** key).

To check the leaks, the **LEAK** key must be used. The following menu then appears:

	ALTITUDE	AIRSPEED	RATE	
SIM	Ps1	29.215	0.001	SIM
CMD	Pd2	29.215	0.001	CMD
SIM	Pt	29.215	0.001	SIM
CMD	Sec. 25	A.O.A. [in]	LEAK	CMD
	Pst	Qc/Ptot	MACH	

where the second (middle) column indicates the pressure actual values for each line, and the third (right hand) column indicates the pressure losses. **Sec.** refers to the time and **LEAK** indicates the operative mode. To return to **ALTERNATIVE CONTROL MENU 2**, the **CNTRL** key must be pressed.

To return to the standard mode of operation, press the **SHIFT** - keys, select Menu 0, and press the **ENTER** key.

WARNING

In A.O.A. MODE , the Pascal Unit for pressures is not available.

10.5 FUNCTIONS DEACTIVATED IN THE A.O.A. MODES

To recap, in the A.O.A. MODE, with ALTERNATIVE CONTROL MENU 1 and 2, the following functions are no longer active:

- QNH (Refer to Sect. 12.2)
- Display Setting (Refer to Sect. 12.1)
- Battery Status Charge (Refer to Sect. 12.3)
- Operation by means of Remote PC (Refer to Sect. 12.4)
- True Airspeed (Refer to Sect. 12.5)
- Enhanced Resolution (Refer to Sect. 12.6)
- Date and Time (Refer to Sect. 12.7)
- Center Line Correction (Refer to Sect. 12.8)
- Valves Fine Tuning Map (Refer to Sect. 12.9)
- E.P.R. (Refer to Sect. 12.12)
- Encoder Readout (Option) (Refer to Sect. 12.13)
- Activating/Deactivating Functions (Refer to Sect. 12.14)
- Activating/Deactivating Oscillation Function (Refer to Sect. 12.15)
- Ultra Low Speed (Refer to Sect. 7)
- Quick Calibration (Refer to Sect. 16.5)

The Multiple Isolator is active only for Static Pressure and A.O.A. Pressure.

10.6 A.O.A. MODES BY DEFAULT

By default, the MPS 35C starts operating with the 0 MENU. The previous paragraphs have been dedicated to the A.O.A. mode of operation.

To set the MPS 35C for starting up directly with the A.O.A. MENU 1 or MENU 2, consult the MPS 35C Calibration and Adjustment Manual where instructions to achieve this modification are given.

10.7 ANGULAR DEGREES VERSUS PRESSURE RATIO RELATIONSHIP

As already mentioned, there is a linear relationship between the degrees on the A.O.A. and differential pressure generated on the aircraft pitot tube.

This relationship is linked to the operating features of each individual aircraft.

To modify this parameter to adapt to the different aircraft it is necessary to go to the FINE TUNING Section, restricted to skilled operators, consult the MPS 35C Calibration and Adjustment Manual where instructions to achieve this modification are given.

For the calibration of the MPS 35C third pressure transducer, that sensor which is responsible for the A.O.A. function, please refer to The Calibration and Adjustment manual.

WARNING

For permanently saving parameter variables, please refer to Section 12.11.

10.8 A.O.A. PRESSURE ZERO ADJUSTMENT

The MPS 35C is supplied with an A.O.A. auto-zero function.

For an accurate A.O.A. measurement, it is recommended to carry out, at ambient pressure, the zeroing operation, in order to bring to zero the value of the difference between the Static pressure and the A.O.A. pressure values.

Operate as follows:

- Place the MPS 35C in the CONTROL MODE;
- Vent the equipment to ambient pressure;
- Once the equipment is at ambient pressure, enter into the A.O.A. MODE, MENU. 2 and set the $P_{s2} = 0.000$ "Hg.
- Wait until the equipment stabilizes the P_{s2} channel to a value very close to 0,000 "Hg.
- If a value very close to 0,000 "Hg cannot be reached, press the CAL (SHIFT MEM) keys; at this point the MPS 35C will show the following reading: TO CALIBRATE P_{s2} , press again CAL.
- Press again the CAL (SHIFT MEM) keys; the P_{s2} reading will now reach the value of 0,000 "Hg.




FIG. 3 – A.O.A CONNECTION TO MPS 35C SCHEME

SECTION 11 - SAFE MANUAL OPERATION

11.1 CONDENSATE DRAINAGE SYSTEM

The MPS 35C is equipped with a condensate drainage system. With MPS 35C in prolonged use, it is recommended that the user executes the removal operation of any water once a month:

To do this, press the condensate removal button on the front panel (Fig. 1 - 9) 2 or 3 times.

11.2 MANUAL VENT

In the event that the MPS 35C suffers a power loss and also an exhausted battery, the Vent operation can also be executed manually.

The two needle valves (Fig. 1-4, 1-5), located on the front panel, are used for manual venting.

Turn counter clockwise to open the two needle valves.

The needle valves must be rotated together, very slowly, to avoid that excessive values of rates. Rotation of Pitot Vent needle Valve too quickly can increase the pitot pressure rate too much, and an rotation of Cross Bleed needle Valve too quickly can increase the Altitude Rate too much.

CAUTION

When the manual venting is completed, the two needle valves must be turned fully clockwise to close them, to restore the seal on pneumatic circuit. Do not over tighten.

SECTION 12 - SPECIAL FUNCTIONS

12.1 SETTING DISPLAY

To set the contrast and back light of the display, press **(SHIFT 1)**, then follow the menu instructions.

12.2 QNH READING

This mode is activated by pressing the **(SHIFT 2) = F2** keys.

In this display the Operator can read the relevant QNH value inHg., if the altitude level of the local airfield in feet has been previously memorized. Please refer to Calibration and Adjustment Manual

To exit the QNH READING MODE and return to the CONTROL MODE of operation, press the **ENTER** Key.

12.3 BATTERY CHARGE STATUS

The internal battery provides more than 180 minutes of continuous operation. To check the battery charge status press the **(SHIFT 3) = F3** key; then **HALT** key to return to the main menu. If the battery reaches a lower than safe level, the display signals, at regular intervals, the reduced life (this function is not operating when the equipment is running the test profiles).

The battery recharge is automatic, whenever the test set is connected to the power supply and the master switch is not in the CENTRE position.

12.4 MPS 35C OPERATION BY MEANS OF REMOTE PC

To activate the external control, the MPS 35C must be connected to an external PC, and **(SHIFT 4) = F4** key must be pressed. Then, press the **ENTER** key to activate external control, or any other key to return to main menu.

With the external control activated all operations are carried out through a PC - the keypad is no longer active.

For operation with external PC, please refer to ADTWIN MPS 35C Manual.

Press the **ENTER** key on the MPS35C keypad to stop PC control and transfer commands back to the Console keypad. Physical connection to the PC is made via the Remote Hand Terminal Serial Port (RS232).

12.5 TRUE AIRSPEED

For True airspeed the **(SHIFT 5) = F5** is used to switch from the default I.A.S. (Indicated Air Speed) to T.A.S. (True Air Speed). The menu requires the operator to input the temperature for the true airspeed.

A "T" before the simulated Airspeed warns the operator that the TAS is the displayed value and not the IAS.

To restore the equipment to the IAS read out, press again the **(SHIFT 5)** keys.

12.6 ENHANCED RESOLUTION

The **(SHIFT 6) = F6** key activates the enhanced resolution function for pressure reading. To return to normal resolution press **(SHIFT 6) = F6** once again.

NOTE

When the Enhanced Resolution function is activated the equipment will always show the actual pressure values in "Hg, regardless the engineering unit which had been selected to enter the target value.

12.7 DATE AND TIME

To change the date and time on the internal clock press **(SHIFT 7) = F7** then follow the menu instructions.

12.8 CENTER LINE CORRECTION

If an altitude difference between the MPS 35C and the UUT exists, the **(SHIFT 8) = F8** function key can be used to allow for, and compensate for, this difference. If the altitude value of the UUT is above the ADTS, the correction value must be a positive integer.

An asterisk " * " before the READ Altitude shows the operator that the corrected altitude is displayed. To cancel this feature enter a zero (0) value for the correction.

12.9 VALVES FINE TUNING (MAP)

The control valves condition can vary over the life of the equipment and can be the reason for a malfunction or poor performance of the control precision

Whenever the equipment does not stabilise properly at the target values it is recommended the valve tuning procedure is carried out, (which is fully automatic) to restore the equipment to the correct condition. Consult the MPS 35C Calibration and Adjustment Manual where instructions of how to carry out this valve tuning exercise are given.

12.10 FINE TUNING FUNCTION

Refer to the MPS 35C Calibration and Adjustment Manual for more details of the performance "Fine Tuning" function of the air data test set.

12.11 SAVING VARIABLE PARAMETERS

Refer to the MPS 35C Calibration and Adjustment Manual for more details for saving variable parameters

12.12 E.P.R. (ENGINE PRESSURE RATIO)

The Engine Pressure Ratio (i.e., Pt/Ps) function is available for the testing of gas turbine engine pressure ratios. It is carried out starting from a desired static pressure value (inlet pressure) in inHg and with the Altitude Rate selected to any value other than zero.

Connect the system to be tested following the aircraft maintenance manual procedures and press the **EPR** key **(SHIFT LIMITS-UNITS)**. The display will prompt the operator to enter the desired values of the Static Pressure and the aimed EPR value. Enter the desired values to input the Static Pressure in Inches Hg and then the EPR. The MPS 35C will reach and maintain the required Pt/Ps value.

On the display **EPR** will appear down at the right hand corner indicating that the MPS 35C is operating in the E.P.R. mode.

The E.P.R. value will be shown instead of Total Pressure.

To return to the normal, ADTS, mode, the CONTROL MODE of operation, press the **CNTRL** key.

12.13 ENCODING ALTIMETER READING (OPTION)

The front panel connector (Fig.1-14) is used to connect the Encoding Altimeter or Encoding Device to test the altitude reporting Gray code; by manufacturing a suitable cable any unit can be tested.

When an Encoding Altimeter/Encoding Device is to be tested, connect it to the MPS 35C, before the ADTS is powered ON.

To either enter or exit the ENCODING ALTIMETER/ENCODING DEVICE TEST MODE, press the keys **SHIFT . 1 2 3 4**.

In the **last row** of the display the Altitude Value corresponding to UUT encoded output will appear on the right, after the letters CF, while on the left side the Gray Code will be shown.

NOTE

On the last page of this manual can be found the wiring diagram for the adapter cable to connect the UUT to the MPS 35C.

In addition to showing the encoded Altitude Value and the Gray Code, the equipment will also provide the following information:

- 1) An acoustic sound (beep) will warn the operator at each altitude transition point.
- 2) A longer acoustic sound will warn the operator when the encoding output is not matching the direction of the applied pressure (for example, when the altitude value is increasing while the encoded Altitude is decreasing or vice-versa).
- 3) The equipment will show all the errors which have been found during the test; to view these errors the **SHIFT MEAS** keys must be pressed.

The errors which have been found will be displayed in the following codes:

- ChErr:='*' When the encoding code is not sensible with altitude variation.
- ChErr:='?' In the presence of a non reliable encoding code.

For example:

1. 00000110011 * 891
2. 00000110001 * 750
3. 00000000000 ? 1630

To exit the error menu, just press the **ENTER** key.

12.14 ACTIVATING/DEACTIVATING FUNCTIONS

By using the **(SHIFT 0) = F0** keys followed by password 0088 it is possible to ACTIVATE/DEACTIVATE the following functions:

- LIMITS
- PROFILES
- EPR
- CENTERLINE
- TAS
- VERY LOW AIRPSEED
- ENHANCED RESOLUTION
- ACOUSTIC ALARM BEEP BEEP
- BATTERY LEVEL
- QUICK CALIBRATION

The menu shows the actual set (for example: LIMITS ON means that the limits function is active, LIMITS OFF means that the limits function is not active).

To toggle ON/ OFF use the arrow **▲** (or **▼**) keys, to select the desired setting. Press **ENTER** as many times as it is necessary to exit the menu.

To permanently save the new selection refer to Section 12.11.

It is strongly recommended to avoid changing the factory default setting.

12.15 ACTIVATING/DEACTIVATING THE MODULATION FUNCTION

The MPS35C provides the ability to set an oscillation signal onto the airspeed and altitude steady state values to allow system behaviour examination.

The modulation function of the Altitude or Airspeed channels is activated as follows:

- 1) Press the **SHIFT** **000** keys.
- 2) To select the channel to be modulated, Altitude or Airspeed, use the UP (DOWN) triangular keys **▲** (or **▼**).
- 3) First select the modulation amplitude - less than 100ft for altitude, and between 100 and 300 knots airspeed. Then select the frequency – 0.05 Hz to 0.5 Hz either altitude or Airspeed.
- 4) To revert to the normal control function press either the **HALT** or the **CNTR** keys.

CAUTION

The activating/deactivating of the modulation function is not possible when operating with A.O.A. menus.

12.15 SPECIAL FUNCTIONS KEYS SUMMARY

F1 (SHIFT 1)	Display Visibility Setting
F2 (SHIFT 2)	QNH reading
F3 (SHIFT 3)	Battery charge status check
F4 (SHIFT 4)	External remote control activation
F5 (SHIFT 5)	TAS / IAS selection
F6 (SHIFT 6)	Enhanced resolution activation
F7 (SHIFT 7)	Date and Time
F8 (SHIFT 8)	Centre Line Correction
F9 (SHIFT 9)	(Code) Static valves map activation (Code) Pitot valves map activation (Code) A.O.A. map activation
F0 (SHIFT 0)	(Code) Fine tuning activation (Code) To activate/deactivate functions
SHIFT •	(Code) Toggle switch to select (remove) Pressure Rates

NOTE

For details of coded operation see MPS35C Calibration and Adjustment Manual

SHIFT **MULTIPLE ISOLATOR** To activate (remove) Encoder reading Option

SHIFT **000** Activating/Deactivating Modulation Function

F - (SHIFT -) To activate A.O.A Mode of Operation

E.P.R. (SHIFT **LIMITS**) E.P.R. Mode activation

MEM To memorise Parameters

SECTION 13 - USE OF HAND HELD REMOTE CONTROL UNIT

The external Hand Held Remote Control Unit (HHRCU) – with or without the wire extension – can also be used instead of the front panel keypad.

To use the Hand Held Remote Control (HHRCU), connect it to the Air Data Test Set by the connecting plug on the front panel (fig. 1-7), before switching on the MPS 35C.

When the HHRCU is connected, it is possible to transfer the Air Data test Set Commands from the front panel keypad (Console) to the HHRCU and vice versa.

After switching on the MPS 35C, wait until start-up operation is concluded. By default, front panel keypad is connected; therefore:

- to transfer the Commands from front panel keypad to HHRCU press the 2 key on the HHRCU keyboard;
- press 1 key on front panel keypad (Console) to transfer back again the Commands from HHRCU to the front panel.

It is possible to transfer the Commands from the front panel to HHRCU and vice versa only in the CONTROL, or MEASURE, or HALT MODE.

When - by default at start-up - the Commands are set on the front panel, it is alternatively possible to start-up having the Commands set on HHRCU: to do this press repeatedly the key 2 on HHRCU keyboard during the start up process, beginning immediately after switching on the MPS 35C.

When - by default at start up - the Commands are set on HHRCU, it is also possible to start-up having the Commands on the front panel: press repeatedly the key 1 on Console keypad during the start up, beginning immediately after switching on the MPS 35C.

The Remote Control Commands are the same as the keyboard with some small differences: the HHRCU has LCD brightness adjustments located immediately under the display area. Some of the keys are slightly different in actual location compared with the console front panel keypad.




FIG. 4 – HAND HELD REMOTR CONTROL UNIT

SECTION 14 - SET PROFILES

If a particular test profile (a set of test points, each one identified by Altitude, Airspeed, Altitude Rate and Airspeed Rate) must be frequently carried out (for example, when required by a particular UUT test specification), the equipment can be easily programmed to memorize such a profile, then, when it is required, it can be selected to carry out the test automatically.

During the automatic testing the equipment will go to all test points which have been previously programmed and memorized.

The keys which are to be used for programming a test profile are:

- The **PROG** = (**SHIFT EXEC**) key is to be used when a new test profile must be programmed or when an existing test profile is to be modified.
- The **EXEC** key is to be used when a selected test profile must be run.

WARNING

Test profiles cannot contain Angle of Attack parameters

14.1 SELECTING, PROGRAMMING OR CHANGING A TEST PROFILE

When in CONTROL MENU, by pressing **PROG** = (**SHIFT EXEC**) key, a new menu will appear to allow the operator to insert a new test profile or to select a test profile to be modified.

It is suggested, to simplify the operation, to prepare (or modify) a new test profile that the test is defined, with a notebook and the proper aircraft maintenance manual – in an office environment.

It is possible to memorize up to 30 different test profiles, containing up to 26 control points, each one consisting of the following parameters:

Altitude: _____	Airspeed: _____
Alt. Rate: _____	Air. Rate: _____
Wait: _____	L0: _____ L1: _____
Pr.1 >: _____	Step.: _____

where:

- "Altitude" is the altitude in feet
- "Airspeed" is the airspeed in knots
- "Alt. Rate" is the altitude rate
- "Air Rate" is the airspeed rate
- "L0" is the stabilization time, once the target step has been reached (max. 99 seconds)
- "L1" is the leak test time to measure the leakage at that point (suggested time is 60 seconds)
- "Wait" is the total time to wait before proceeding to the next step.
- "Pr.1 (2,3,4, etc.)" identifies the program number selected .
- "Step." shows the selected profile step identified by an alphabet letter a,b,c etc .

After pressing the **PROG** = (**SHIFT EXEC**) key, the operator can select a new test profile or select the test profile which has to be modified (i.e. 0,1,2,3...etc) .

After having entered program No., the program will ask the operator to enter the stabilisation time.

STABILIZATION TIME

This is the portion of the **WAIT TIME** which remains available to the operator to take a reading before the equipment will be ready to go the next test point. Different **WAIT TIME** periods can be programmed for each test point. The **STABILIZATION TIME** however will always be the same for all the test points; the waiting time must always be set greater than the stabilisation

time. Depending on the test requirements it is suggested a **STABILIZATION TIME** between 10 and 15 seconds is selected and a **WAIT TIME** not less than 30 seconds. During the test a low frequency bee-beep will warn the operator that the equipment has reached the target value (**WAIT TIME**); once the stabilisation time has been reached, a beep-beep at a much higher frequency will warn the operator to take the reading at this test point, before the stabilisation time ends.

Once entered by the operator the stabilisation time, by pressing **ENTER** key, the programming sequence will start from the symbol "-" placed on last letter of program name (8 letters max).

To enter the name for the new test profile, or to modify an existing one, press the **BACKSPACE** key 8 times to scroll the cursor onto the initial letter. It is now possible to write the required letter by using the keyboard in the same way as the phone keyboard.

Please refer to the following table;

- [1] ==> space < = > 1
- [2] ==> a b c 2
- [3] ==> d e f 3
- [4] ==> g h i 4
- [5] ==> j k l 5
- [6] ==> m n o 6
- [7] ==> p q r s 7
- [8] ==> t u v 8
- [9] ==> w x y z 9
- [-] ==> - + * /
- [0] ==> @ # & % 0
- [.] ==> . , \ _ "

By default the first letter to be written is a Capital Letter; by pressing the **▼** key it is possible to select the lower case letters;

press again the **▲** key to return to the capital letters.

Once the required letter or symbol appears in the desired position the **ENTER** key must be pressed and the symbol "-" will move to the next position. Repeat all the above until the name of the test profile is fully entered.

NOTE: If a mistake occurs in this phase, it is possible to correct it by pressing the **BACKSPACE** key and retyping the character.

Once the name has been fully (8 characters maximum) entered, the sequence will now move on;

A ">" will flash in front of the Altitude value (Alt): insert the altitude value for the first step or confirm the existing one by pressing the **ENTER** key. To move the ">" symbol into the front of Airspeed value (Asp), use the > key.

Insert the Airspeed value to be simulated at that point or confirm the existing one by pressing **ENTER** key.

Enter in the same way the Altitude rate and Airspeed Rate values.

When the cursor ">" symbol flashes in front of "Wait", the value to be entered corresponds to the time (in seconds) that the equipment must wait before moving automatically to the next step. If 0 (zero) value is entered, the MPS 35C will not pass to the next step unless the **▲** (up arrow) is pressed.

NOTE:
Even if a value different to 0 is entered, it is always possible to pass to the next step by pressing **▲** or to the previous one by pressing the **▼** keys.

The next parameters L0 and L1 must be entered if a leak test is required at this test point

(LEAK). After the waiting time has been entered and a leak test it is to be carried out at this step, move the arrow prompt ">" in front of L0: this corresponds to the stabilization time for the leak check, that is time in seconds to stabilize before measuring the leaks into both lines. If a zero value is entered, the equipment will not perform any stabilization time for the leak test.

When the stabilization time has been set, move the cursor ">" in front of L1: this is the measuring time for the leak test (that is time in seconds to measure the leaks). If "0" (zero) value is entered, the equipment will not perform leak measurements.

When the equipment has carried out the leak test, the LEAK WAIT will appear meaning the remaining time to complete the leak test. (This will depend on the leak waiting time which has been set. The stabilisation time is usually 60 seconds plus an additional time of 60 seconds to run the leak test, for a total of 120 sec.)

When leak test has been completed the following will be displayed:

- RA indicates the leakage of the static lines (feet/min.)
- RS indicates the leakage of the pilot lines (knots/min.)
- WAIT 999 means the ▲ (up arrow) key must be pressed to go to the next step.

NOTE

If a leak test has been programmed, it is recommended to select a wait time which gives the operator enough time to control the leak, or better, to select a wait time equal to zero so that the next step will be reached only after the ▲ (up arrow) key is pressed.

When all the profiles have been programmed, or at any time, press the HALT key to exit the programming menu and return to CONTROL MENU. If a new profile has been entered (or an existing one has been modified), the display will need to memorise it : to save the new test profile, press the MEM key twice, the ADTS will save the profile permanently in non volatile store (even when the power is switched off). Otherwise press the HALT key and the new profile or the profile modification, will be lost.

14.2 EXECUTING A SELECTED TEST PROFILE

To carry out a test by using a programmed profile, press EXEC key: a new menu will be displayed and it will request the operator to select the desired test profile number (0,1,2,...29); enter the profile identification number and press the ENTER key.

Automatic testing will start and the equipment will generate the pressures corresponding to all the test points entered in the profile.

Each test point is identified by a letter (A,B,C,.....Z).

When the equipment is working in the AUTOMATIC MODE, on the last row of the display the Test Profile Number (1,2...), the Profile Name (for example HELICOPA) and the Step Point which is active (A,B,C,.....Z). are shown in lieu of the normal indication which appears in the CONTROL MENU.

To move to the next step, press ▲ key or wait the programmed time. Each programmed step can be reached in this way. To return to the previous step, press the ▼ key.

To use the equipment in CONTROL MODE, press the HALT key to exit the program.

To select another test profile, move to the "CONTROL" MENU and press the EXEC key to insert the new desired program number.

14.3 PROGRAMMING EXAMPLE

If an operator wants to execute a leak test on the static line of an helicopter at 10,000 feet and then on the pitot line at 150 knots he can program it as follows:

Memorise the two program steps in an hypothetical profile named, for example, HELICOPA, as follows:

a) Step A: static leak test at 10,000 feet:

Altitude: 10000

Alt. Rate:3000

Wait:90

L0: 60

Airspeed: 0

Air. Rate:0

L1: 60

Pr.1 >: HELICOPA

Stp.: A

b) Step B: pitot leak test at 150 knots:

Altitude: 0

Alt. Rate:3000

Wait:90

L0: 60

Airspeed: 150

Air. Rate:150

L1: 60

Pr.1 >: HELICOPA

Step.: B

NOTE:

In the Test Profiles only the values which are required can be entered; for example: the altitude rate can only be entered in feet/min and the pressures rate cannot be entered.

If this profile has been programmed and selected as suggested above, and therefore the **EXEC** key has also been pressed, the profile "1" is loaded into equipment memory with the name HELICOPA. The HELICOPA program will automatically be executed and the equipment will automatically set 10,000 feet as the target altitude with 3,000 feet/minute Altitude rate. Once the set altitude has been reached, the equipment will stabilize the pressure for the next 60 seconds (L0). Then it will measure the static leak for 60 seconds (L1), and after an additional 90 seconds of waiting time (Wait) it will move to the step B. In the mean-time it will indicate leak measured with RA and RS.

The MPS 35C will now execute step B, reaching the 0 feet altitude with a 3,000 feet/minute Altitude rate and then setting the target Airspeed to 150 knots, with a 300 knots/minute of Airspeed rate. Once the target values are reached, the leak will be measured in the same way as in the static line.

14.4 EXECUTING A.O.A SELECTED TEST PROFILE

This option is available only for the ALTERNATIVE MENU 2. It is possible to select from one of 3 memorized TEST PROFILES (number 0, number 1 and number 2), that are useful for many different civilian aircraft. Pressing the PROG = (SHIFT **EXEC**) key or the **EXEC** key it is possible to view (and modify) or automatically execute either the TEST PROFILES 0, as detailed here below: in TABLE 1

Input Values			
(Ps1&Ps3) ("Hg)	Ps2 ("Hg)	Pt ("Hg)	Rate ("Hg/m)
29,8155	29,8155	29,9268	4,0
29,8261	29,8261	30,2692	4,0
29,8461	29,8461	30,8654	4,0
29,8783	29,8783	31,7264	4,0
29,9238	29,9238	32,8492	4,0
29,9909	29,9909	34,2646	4,0
30,0823	30,0823	35,9890	4,0
31,0185	31,0185	31,0185	4,0
29,9213	29,9213	29,9213	4,0
29,3846	29,3846	29,3846	4,0
28,8557	28,8557	28,8557	4,0
28,3345	28,3345	28,3345	4,0
27,8210	27,8210	27,8210	4,0
26,8167	26,8167	26,8167	4,0
25,8418	25,8418	25,8418	4,0
23,9782	23,9782	23,9782	4,0
22,2249	22,2249	22,2249	4,0
20,5769	20,5769	20,5769	4,0
17,5774	17,5774	17,5774	4,0
14,9421	14,9421	14,9421	4,0
11,1040	11,1040	11,1040	4,0
8,8850	8,8850	8,8850	4,0
7,0409	7,0409	7,0409	4,0
5,5380	5,5380	5,5380	4,0
4,3550	4,3550	4,3550	4,0
3,4250	3,4250	3,4250	4,0
11,1066	11,1066	11,2167	4,0
11,1184	11,1184	11,5696	4,0
11,1421	11,1421	12,1720	4,0
11,1833	11,1833	13,0259	4,0
11,2478	11,2478	14,1552	4,0
11,3501	11,3501	15,5786	4,0
11,6075	11,6075	17,3212	4,0





or alternatively the TEST PROFILE 1, as detailed below in TABLE 2

Input Values			
(Ps1&Ps 3) ("Hg)	Ps2 ("Hg)	Pt ("Hg)	Rate ("Hg/m)
21,4923	20,1107	21,1281	4,0
21,3983	20,2017	21,3073	4,0
21,3010	20,2486	21,4384	4,0
21,1967	20,3245	21,5404	4,0
20,9808	20,4404	21,6404	4,0
20,7750	20,5083	21,6527	4,0
20,6874	20,5482	21,6522	4,0
20,5495	20,6886	21,6522	4,0
20,5078	20,7746	21,6527	4,0
20,4403	20,9808	21,6404	4,0
20,3245	21,1966	21,5404	4,0

Or alternatively the TEST PROFILE 2.

Test Profile 2 is a format to be determined by the Operator using the above general format and allowing a specific test routine to be defined as desired.

The 3 memorized TEST PROFILES (each one can contain up to 33 different test points). can be changed by:.

- entering the TEST PROFILE program, pressing the **PROG** = (SHIFT EXEC) keys;
- selecting the TEST PROFILE 0, or 1, or 2 with the arrow  (or ) keys;
- scrolling the values and the test profiles points with ( or ) keys and modifying requested values;
- memorizing the new TEST PROFILES values (pressing twice the **MEM** key), before exiting out of the program by pressing the **HALT** key.

SECTION 15 - TEST RESULTS SAVING AND TRANSFER

15.1 GENERAL

The MPS 35C is supplied with the "USB port"(see figure 1.17) option.

With this option it is possible to memorize all the test results. For each test point it is possible to memorize the reading of the UUT and the test value generated by the MPS 35C (which is assumed to be the reference value). The results are in the engineering unit which has been previously selected (for example feet and knots or metres and Km/hour, etc.). All the data can be transferred to a PC, on which they can be managed as necessary (printed, saved on hard disk, or manipulated).

To start the saving of Test Results.

- Before switching ON the MPS 35C, insert the USB pen (enclosed with ADTS) inside the USB port, as showed below (see Par. 15.7).
- After MPS 35C starting up procedures, once in CONTROL MODE, press in sequence the keys **SHIFT SHIFT 0**.



The program allows the memorizing of the following data:

- The operator's name (a minimum of 3 characters must be entered)
- The A/C name
- The positions the UUT, (Capt, F/o and Stby) which can be selected by pressing the **▲** or **▼** keys.
- For each individual unit up to 26 test points can be saved (the test points can also be recalled from TEST PROFILES; refer to Section 13 - TEST PROFILES PROGRAMMING).

The program will automatically assign:

- a) The Name of the Test (this will be generated by taking into account: month, day, hour and minute).
- b) The date on which the test has been performed.

When all the test points have been saved onto the MPS 35C USB pen, turn OFF the MPS 35C and remove the pen which can be connected to any PC having an USB port.

All the data can then be managed in the PC and printed.

The program will operate as follows:

15.2 TEST RESULTS MEMORIZATION MODE CONFIGURATION

The MPS 35C must be configured to save the test results before beginning of the test.

WARNING:

The USB pen must be inserted into the proper slot, before the MPS 35C is turned on and should be removed only after the test set has been turned off.

The program will allow the operator to exit at any time from the MEMORIZATION MENU, and go to the CONTROL MENU by pressing the **HALT** key.

To start the CONFIGURATION MENU, press the **SHIFT SHIFT 0** keys.

Note

If the USB pen has not been inserted properly into the slot, or if it is even slightly damaged, or the memory is full, the following will appear:

**Insufficient space
Any Key to EXIT**

If the **ENTER** key is pressed the program will automatically assign:

- a) The Name of the Test (this will be generated by taking into account: month, day, hour and minute in hexadecimal code);
- b) The A/C name
- c) The date on which the test has been accomplished

The program will then require the operator to enter:

- 1) The operator name, where three characters minimum must be entered.(10 characters maximum)
- 2) The UUT position
- 3) The type and position of UUT selected among the following ones, by using the **▲** and **▼** keys .
 - Capt.
 - F/o
 - Stby

NOTE:

Up to 3 UUTs positions (Capt, F/o and Stby) can be stored into the program.

WARNING:



If the operator name is not entered with more than 2 character the Configuration is not valid and the test results cannot be memorized and displayed.

After the **ENTER** key has been pressed and no readings of the test results have been properly entered, the equipment will memorize the test results only for that (or those) instrument(s) for which the test readings have been properly entered.

If the test readings are not entered for at least one UUT, test results cannot be memorized and displayed.

To enter any type of data use the keyboard in the same way as the telephone pad:

- [-] ==> - + * /
- [.] ==> . , \ _ "
- [0] ==> @ # & % 0
- [1] ==> space < = > 1
- [2] ==> a b c 2
- [3] ==> d e f
- [4] ==> g h i 4
- [5] ==> j k l 5
- [6] ==> m n o 6
- [7] ==> p q r s 7
- [8] ==> t u v 8
- [9] ==> w x y z 9

By default the program will write CAPITAL letters; to go to small letters press the  key; to switch back to capital letters press the  key.

To clear the last entered digit use the **BACK SPACE** key.

To validate the digitized data press the **ENTER** key.

For reference the HHRCU (Hand Held Remote control Unit) keyboard is shown in the next page.

15.3 TEST RESULTS RECORDING

Once the test point has been reached and the pressures stabilized, by pressing **SHIFT SHIFT 1**, the display will show a mask to memorize the test results; the operator should enter the readings on the UUTs while the values generated by the ADTS will be entered automatically.

The test points can be reached in either the manual mode (see Section 4) or in the Automatic Mode (See Section 10); for this mode the following should be noted;



Before starting the test that is to be memorized it is mandatory to enter all the data which are required in the paragraph: TEST RESULTS MEMORIZATION MODE CONFIGURATION; in particular it is absolutely necessary that the operator is clearly identified by entering at least 3 characters.

The memorization mask will appear automatically, after the stabilization time has elapsed; the program will not allow the ADTS to move to the next test point until the operator has entered the required data.

The memorization mask, which is always the same regardless the mode employed (manually by pressing **SHIFT SHIFT 1** or automatically by pre-programmed profiles), consists of some data which the operator cannot modify e.g.

- 1) The name and date of the testing (which has been assigned automatically by the program at beginning of test);
- 2) The UUT(s) identification data (position: Capt. F/O and STBY);
- 3) The number of each of the test points, since it is automatically generated by the program.

The data on which the operator can operate are:

1. The UUT type (ALTIMETER, AIRSPEED INDICATOR or MACHMETER); where the cursor will go to the first instrument for which the data are to be memorized, insert the data and press the **ENTER** key to save data for that instrument or use the  and  keys to move to other UUTs
2. The UUT reading at each test point.

After all the data for a particular test point have been entered and validated by pressing the **ENTER** key the program will go the next UUT for which the test results are to be memorized.

After all the UUTs test results have been entered, by pressing again the **ENTER** key the program will put the MPS 35C in CONTROL MODE if a manual test is being carried out (in order to allow the operator to enter the next test point), or it will command the MPS 35C to the next test point if an automatic test profile is in progress.

The procedures which are described above must be applied for each test point.

15.4 TEST RESULTS READOUT

The memorized test results can be read by pressing the **SHIFT** **SHIFT** 2 key in the MENU CONTROL.

A mask with the data of the UUTs tested will appear. Use the **▲** or **▼** keys to select the UUT for which the data must be displayed. At this point press the **ENTER** key; all the test points which have been memorized will appear; since all the points cannot be shown in one single display; use the **▲** or **▼** keys to scroll through the display to see all the test points results.

The display will show:

- The identification data of the UUT.
- The number of the Test Point (1,2.....)
- The values generated by the MPS 35C, named S (As Set) and the UUT memorized readings named R (as Read).

Press the **HALT** key to exit the menu and put the MPS 35C back in the CONTROL MODE.

15.5 TEST MEMORIZATION

The data of the test can be memorized in the USB pen by pressing the **SHIFT** **SHIFT** 0 key; with this command it's possible to start a new test, or memorize the last one. For this second option the program will require to press again the **MEM** key to confirm .

WARNING:

Once the USB pen has been used to memorize data it can be cleared only on a PC; all the data which have been memorized can be managed or printed only by using a PC.

The data memorization does not mean that the test has been completed; the test can always be recalled at any moment from the test point at which it has been stopped.

To end a test the operator should start another virtual test, as follows:

Memorize the test, as necessary

*Return to the CONTROL MENU and start a new test by pressing **SHIFT** **SHIFT** 0; when the program will require entry of the operators name press the **ENTER** key without writing anything.*

By leaving the TEST RESULTS MEMORIZATION MODE CONFIGURATION, the other test will also be ended.

15.6 DATA MANAGEMENT

At the end of the test, only after the ADTS has been powered OFF the USB pen can be removed and connected to a PC to manage, print or cancel the data as necessary.

15.7 PROFILES PROGRAMMING USING A PC VIA USB

With the MPS 35C, it is possible to create a program test profile on a PC and then load it into the MPS 35C via USB port.

NOTE

In the USB pen memory the following folders must be available, in order to be able to download the profile program written by the PC.

The USB pen must be inserted into the MPS 35C slot with the ADTS powered OFF.

- Profiles:

After having inserted the USB pen when powering on the MPS 35C it will only start if inside the USB pen the files RCRDDMA.dat and RCRDAOA.dat are found.

*The files will be loaded into the MPS39C and renamed as RCRDDMA.*** and RCRDAOA.****

- Reports:

These files must be present in order to have the capability to save and store into the USB pen all the tests results.

The MPS 35C offers the ability to program a Test Profile either directly using the MPS 35C keyboard or by writing them into a PC, store into a USB pen and then transfer them inside the MPS 35C by using the same USB pen.


To do this the following steps must be accomplished:

- Load into the PC I used for programming the test profile the SW Profiles.exe.
- Once loaded open, such profile.
-

The following mask will be available:


- Click on the "file" to get Load or Save.

- Click on Load and to get RCDRAOA.DAT or RCDRDMA.DAT. (see the mask below)



The FormLoad dialog box has a title bar with a folder icon and the text 'FormLoad'. It contains two text input fields. The first field is labeled 'Path' and contains the text 'C:\Profiles\'. The second field is labeled 'Files' and contains the text 'RCRDDMA.DAT'.

- Clicking on the RCRDDMA.DAT it is possible to enter the profiles for the MPS 35C generating two Pressures: Pitot and Static (see the following figure)



The FormDma dialog box has a title bar with a folder icon and the text 'FormDma'. It contains several input fields. At the top, there is a 'File ?' label. Below it, there are three fields: 'n.Pro' with a value of '1', 'Name' with the text 'FAR43nLk', and 'Point' with a value of '1'. Below these, there are four fields: 'Al' with a value of '-1500', 'As' with a value of '450', 'RaAl' with a value of '6000', and 'RaAs' with a value of '300'. Below these, there is a 'Wait' field with a value of '15'. At the bottom, there are two fields: 'L0' with a value of '0' and 'L1' with a value of '0'.

- Select which profile "Name" needs to be changed or updated; then change all the data for each test point which is inside the profiles.
- Proceed step by step changing the values as necessary. To go from one Test Point to another clicking on the right hand side of the "Point" to increment.

SECTION 16 - CALIBRATION

As delivered, the MPS 35C (ADTS) has been calibrated with a very precise pressure Transfer Standard (TStd) and its precision is guaranteed within 3 ft @ s.l. for 1 year.

The calibration procedure achieves the target accuracy if the following conditions exist:

- Acceptable uncertainty of the primary standard value at the measurement points.
- Internal Pressure Transducers not damaged.

The calibration is made by changing the zero and the gain values.

Full details for the Calibration process are given in the MPS 35C Calibration and Adjustment Manual.

16.1 DURATION AND SERVICE

The MPS 35C is specified to conform to the Specification and to comply with the requirements of RVSM for a period of 12 months before requiring a verification calibration.

In Italy D. Marchiori s.r.l. maintain S.I.T. accredited Calibration Laboratory No. 106, guaranteeing low uncertainties outside the National Physical Laboratory for the air data pressure range.

16.2 COMPANY CALIBRATION SERVICE

D. Marchiori s.r.l. specialises in the service, maintenance and calibration of Air Data Test Sets and other aerospace and meteorological instrumentation, and will be happy to support your test equipment.

Centro Taratura S.I.T. 	D. MARCHIORI S.r.l. – AIRCRAFT GROUND EQUIPMENT Sede legale e Stabilimento Via Pontina Km. 43,856 – 04011 Aprilia (Latina) - Italy Cod. Fis. 00083240598 - Part. IVA 01284180591 Tel. :06/92703073/9282733 Fax: 06/9275401 e-mail: d.marchiori@mclink.it web p.: www.dma-aero.com	ISO 9001 2000
---	--	---------------------

SECTION 17 - ADTS CONTROL PARAMETERS FOR VARIABLE TUNING

The various control parameters associated with the performance, operation and accuracy of the instrument are all detailed in the MPS 35C Calibration and Adjustments Manual and are only relevant to trained personnel while carrying out special functions.

18 - TECHNICAL SPECIFICATIONS

18.1 AIR DATA FUNCTIONS

The MPS 35C generates the following air data test outputs:

- Altitude and Rate. (for PS1, and also PS2, for A.O.A.)
- Static pressure in various engineering units.
- Air speed and Rate.
- Total (or Differential) pressure in various engineering units.
- Mach Number.

18.2 ACCURACY

•Altitude:

- Range: -3,000 to +80,000 ft with the internal compressor/vacuum pump
: for A.O.A testing the delta P range is approx. 3 in Hg diff. (100hPa diff.)
- Measuring accuracy:
- ± 3 ft @ sea level with reference to the primary standard;
- ± 5 ft @ at 30,000 ft reference to the primary standard;
- ± 20 ft @ at 60,000 ft reference to the primary standard.
- Resolution: 1 ft
: for A.O.A the resolution is 0,001 in Hg
- Accuracy control: ± 2 ft @ 20,000 ft without leakage
: for A.O.A the accuracy of control is 0,003 in Hg

•Vertical speed:

- Range: 0 to 6,000: the maximum value can be raised to 30,000 ft/min, or lowered with keyboard
- Resolution: 25 ft/min > 1000, 5 < 1000
- Accuracy of the vertical speed control: $\pm 10 \pm 1\%$ of reading

•Airspeed:

- Range: 10 to 850 kts, with internal pumps
- Accuracy: ± 0.5 kt @ 50 kt; ± 0.1 kt @ 500 kt
- Resolution: 0.1 kt under 50 kt, 1 kt over 50 kt
- Generated airspeed rate: default is 300 kt/min.; can be set with keyboard from 0 to 700 kt/min.

•Ultra Low airspeed:

- Range: 2 to 200 kts,
- Accuracy: ± 0.001 inHg
- Resolution: 0.1 kt > 20 kt.

•Airspeed slew rate:

- Range: 0 to 700 kn/min.
- Resolution: 10 knots
- Accuracy: $\pm 5\%$

•Mach number:

- Range: 0.200 to 6.000
- Accuracy: ± 0.002 Mach @ s.l
- Resolution: 0.001 Mach
- Repeatability: 0.001 Mach

18.3 POWER SUPPLY REQUIREMENT:

It is possible to connect the ADTS to power supply sources ranging from;

- 90 to 240 V ac, from 50 to 400 Hz.
- Internal battery: approx. 4 hours of use
- Electrical input: 120 W Maximum

WARNING: VOLTAGES HIGHER THAN 30 VOLTS (RMS) AC OR 50 VOLTS DC, IN CERTAIN SITUATION, CAN BE LETHAL. CARE MUST BE TAKEN WHEN WORKING WITH LIVE BARE CONDUCTORS.

CAUTION

The instrument's supply must provide a connection to a protective ground terminal.

The unit must, at all times, be connected to the supply Earth. (Ground)

18.4 DIMENSIONS

- Size: 24,4 in (L). x 19,7 in.(W) x 11,8 in.(H) - 620 x 500 x 300 mm
- Weight: 76 lb – 34,5 kg

18.5 ENVIRONMENTAL

- Storage temperature: - 20 to +70 °C
- Operating temperature: -10° to +50 °C

18.6 CALIBRATION

- Performed via internal software through the keyboard (first-level calibration).
- Recoverable error for static and pitot pressure. Without any limitation, it is advisable to send the test set to the manufacturer for an error higher than 2 hPa.
- Self-reconditioning of the control valves is accomplished via internal software, when required to regulate the control parameters of the flow regulators. This operation may be required after long running periods of the test set to re-adapt the software control parameters to the ageing of the pressure control valves.

18.7 SELF TEST TIME AT START UP

Automatic self-test is initiated at power-on. The MPS 35C is ready for operation approx 180 seconds after power-on.

18.8 OPTIONS

- A. Low-voltage power supply option, 22–30 V d.c.
- B. ARINC 429
- C. IEEE488 GPIB Interface
- D. Wireless Bluetooth PDA remote control.
- E. ADWin SW to command the MPS 35C with external PC
- F. Hand Held Remote Control including 60 ft extension cable
- H. Gray Code Altitude Device Readout

18.9 CONTROL CAPABILITY WITH INTERNAL PUMPS

- The control capability is optimized for the following loads: (for special requirements, the MPS 35C can be easily modified for larger volumes):
- Static line: with 125 cu in. (2 litres), the vertical speed can be controlled at 6,000 ft/min up to 50,000 ft.
- Pitot line: the maximum limit speed can be stabilized with a volume of 80 cu in. (1,3 litres).

18.10 COMMAND AND CONTROL

The keyboard has 32 low-profile keys, and a backlit LCD display with two main menus:

- The first menu is the operational one, which shows the target values and the actual values:
 - altitude/airspeed input
 - static/total pressure input
 - altitude/airspeed rates input
 - Mach Number input
 - EPR generation
 - TAS/IAS toggle
 - elevation offset correction
- The second menu is used to set the maximum and minimum parameters according to the system under test, to set the speed (indicated air speed (IAS) variation, and to define the steps AL, AS, and AR to be used during the test.
- The third menu is used to store and transfer test results with compact flash card.
- Automatic leak check
- 30 user programmed test profiles
3 user programmed A.O.A test profiles
- Automatic venting - safe manual venting
- ultra low speed (2 to 200 kts) function
- External vacuum/pressure connection
- Multiple Circuit Isolation

18.11 PROTECTIONS

- Hardware: intrinsically safe, the electro valves, normally closed without electrical power, prevent airflow, and do not generate $P_s > P_t$. Also, the manual valves do not allow the generation $P_s > P_t$; It is allowed only when operating with A.O.A. ALTERNATIVE MENU No. 2.
 - Software: the above condition, negative Q_c , ($P_s > P_t$) is prevented, It is allowed only when operating with A.O.A. ALTERNATIVE MENU No. 2.
 - Software limitations:
 - Max altitude.
 - Max airspeed.
 - Max vertical speed.
 - Max airspeed rate.
 - Max Mach number
- (Note: Airspeed and Mach number always interact. It is, therefore, impossible to overcome the maximum value of one or the other.)

Software protections: if data entered are larger than the software-imposed limits, the ADTS continues and controls the pressures at the limit value.

18.12 PROTECTIONS AGAINST ELECTRICAL POWER LOSS

The internal battery provides safe operation even if the external power is removed.

Also, if the internal battery is completely discharged, nothing happens to the lines under test. When the electric power is restored, the ADTS senses the pressure in the lines and forces the control system to equalize to these measured values.

Pitot and static lines can be manually vented using two flow control valves placed on the front panel of the test set. The manual venting operation does not generate Qc negative pressure, or airspeed exceeding 450 kts.

18.13 EXTERNAL SUPPLY PORTS

The MPS 35C has 2 External ports (Fig. 1-15,16), one for vacuum generation (useful in the case of using flight adapters equipped with suction cups), the other for pressure generation.

These ports can also be used to allow external pressure and vacuum supplies to be used in the event of the internal pumps failing thereby supplying the necessary pneumatic supplies to the instrument.

18.14 MULTIPLE CIRCUIT ISOLATION

The MPS 35C is configured to control up to four static and four pitot lines, allowing isolation, by using the panel keypad or the remote hand controller.

18.15 ANGLE OF ATTACK

The ADTS MPS 35C can set the Angle Of Attack (A.O.A.) parameters, either by the angle in degrees, or setting the corresponding pressure units.

SECTION 19 – ENCODING ALTIMETER CONNECTION DETAILS

The following diagram gives the various pin connections for the Encoding Altimeter interface plug / socket located on the front panel of the MPS 35C.

The User can then manufacture a suitable cable to interface with the specific encoder, which is to be interrogated.




FIG. 6 MPS 35C – ENCODING CONNECTION ELECTRICAL SCHEME