

Hook-Up Chart Bleed Leak Detection wiring (EO B-36-3-001)

Loop Connector	Cable Assy	existing Wire	FROM REF	Contact	Tooling	Wire provided by connector	Splice/Solder sleeve	Splice Kit	Tooling	WDM Reference	Note
MT155P2	KBA670-51561-1	WAG2203-22	P407-H			TLU2203	SP747	D-150-0168	GMT232	36-21-01	
MT156P1	KBA670-51561-3	WAH2212-22	P409-J			TLV2212	SP749	D-150-0168	GMT232	36-21-01	
MT165P2	KBA670-51561-1	WBG2294-22	P406-D			TKU2294	SP746	D-150-0168	GMT232	36-21-02	
MT166P1	KBA670-51561-3	WBH2298-22	P408-G			TKV2298	SP748	D-150-0168	GMT232	36-21-02	
MT167P1	KBA670-51561-3	WAG0589-22	P407-N			TLA0589	SP715	D-150-0318-NF	GMT232	36-21-03	
MT167P2	KBA670-51561-1	WAG0592-22	J803-3			TLB0592	SP717	D-150-0318-NF	GMT232	36-21-03	
MT168P2	KBA670-51561-1	WAH0585-22	P409-L			TLC0585	SP719	D-150-0318-NF	GMT232	36-21-03	
MT168P1	KBA670-51561-3	WAH1096-22	J807-3			TLD1096	SP721	D-150-0318-NF	GMT232	36-21-03	
MT174P1	KBA670-51561-3	WJH0591-22	P813-5			TLN0591	SP739	D-150-0318-NF	GMT232	36-21-03	
MT174P2	KBA670-51561-1	WJH2304-22	P813-4			TLP2304	SP741	D-150-0318-NF	GMT232	36-21-03	
MT173P2	KBA670-51561-1	WJG0586-22	P813-2			TLR0586	SP743	D-150-0318-NF	GMT232	36-21-03	
MT173P1	KBA670-51561-3	WJG2305-22	P813-1			TLT2305	SP745	D-150-0318-NF	GMT232	36-21-03	
MT172P1	KBA670-51561-3	ref. to added wire	J813-4	M39029-58-360	Crimper: M22520/2-01 Positioner: M22520/2-09	WGH2304-22	N/A			36-21-03	Supplied wire should be long enough to install it directly to the related electrical connectors
			J813 Backshell			WGHJ003	B-023-07-55-22-9			36-21-03	Shielding of Wire WGH2304-22. Remove the supplied lead from the acquired solder bands and install existing lead
MT172P2	KBA670-51561-1	WGH2302-22	J811-4			TLF2302	SP733	D-150-0318-NF	GMT232	36-21-03	
MT171P1	KBA670-51561-3	WGG2303-22	J811-1			TLH2303	SP737	D-150-0318-NF	GMT232	36-21-03	
MT171P2	KBA670-51561-1	ref. to added wire	J813-1	M39029-58-360	Crimper: M22520/2-01 Positioner: M22520/2-09	WGG2305-22	N/A			36-21-03	Supplied wire should be long enough to install it directly to the related electrical connectors
			J813 Backshell			WGGJ001	B-023-07-55-22-9			36-21-03	Shielding of Wire WGG2305-22. Remove the supplied lead from the acquired solder bands and install existing lead
MT170P1	KBA670-51561-3	WEH2302-22	P811-4			TLJ2302	SP723	D-150-0318-NF	GMT232	36-21-03	
MT170P2	KBA670-51561-1	WEH1096-22	J809-3			TLK1096	SP725	D-150-0318-NF	GMT232	36-21-03	
MT169P2	KBA670-51561-1	WEG2303-22	P811-1			TLL2303	SP727	D-150-0318-NF	GMT232	36-21-03	
MT169P1	KBA670-51561-3	WEG0592-22	J805-3			TLM0592	SP729	D-150-0318-NF	GMT232	36-21-03	
MT181P1	KBA670-51561-3	WBG2467-22	P406-H			TKA2467	SP714	D-150-0318-NF	GMT232	36-21-04	
MT181P2	KBA670-51561-1	WBG2470-22	J802-1			TKB2470	SP716	D-150-0318-NF	GMT232	36-21-04	
MT182P2	KBA670-51561-1	WBH2468-22	P408-L			TKC2468	SP718	D-150-0318-NF	GMT232	36-21-04	
MT182P1	KBA670-51561-3	WBH2471-22	J806-1			TKD2471	SP720	D-150-0318-NF	GMT232	36-21-04	
MT176P1	KBA670-51561-3	WKH2469-22	P812-5			TKN2469	SP738	D-150-0318-NF	GMT232	36-21-04	
MT176P2	KBA670-51561-1	WKH2474-22	P812-4			TKP2474	SP740	D-150-0318-NF	GMT232	36-21-04	
MT175P2	KBA670-51561-1	WKG2466-22	P812-2			TKR2466	SP742	D-150-0318-NF	GMT232	36-21-04	
MT175P1	KBA670-51561-3	WKG2475-22	P812-1			TKT2475	SP744	D-150-0318-NF	GMT232	36-21-04	
MT178P1	KBA670-51561-3	ref. to added wire	J812-4	M39029-58-360	Crimper: M22520/2-01 Positioner: M22520/2-09	WHH2474-22	N/A			36-21-04	Supplied wire should be long enough to install it directly to the related electrical connectors
			J812 Backshell			WHHJ003	B-023-07-55-22-9			36-21-04	Shielding of Wire WHH2474-22. Remove the supplied lead from the acquired solder bands and install existing lead
MT178P2	KBA670-51561-1	WHH2472-22	J810-4			TKF2472	SP732	D-150-0318-NF	GMT232	36-21-04	
MT177P1	KBA670-51561-3	WHG2473-22	J810-1			TKH2473	SP736	D-150-0318-NF	GMT232	36-21-04	
MT177P2	KBA670-51561-1	ref. to added wire	J812-1	M39029-58-360	Crimper: M22520/2-01 Positioner: M22520/2-09	WHG2475-22	N/A				Supplied wire should be long enough to install it directly to the related electrical connectors
			J812 Backshell			WHGJ001	B-023-07-55-22-9				Shielding of Wire WHG2475-22. Remove the supplied lead from the acquired solder bands and install existing lead
MT180P1	KBA670-51561-3	WFH2472-22	P810-4			TKJ2472	SP722	D-150-0318-NF	GMT232	36-21-04	
MT180P2	KBA670-51561-1	WFH2471-22	J808-1			TKK2471	SP724	D-150-0318-NF	GMT232	36-21-04	
MT179P2	KBA670-51561-1	WFG2473-22	P810-1			TKL2473	SP726	D-150-0318-NF	GMT232	36-21-04	
MT179P1	KBA670-51561-3	WFG2470-22	J804-1			TKM2470	SP728	D-150-0318-NF	GMT232	36-21-04	