

**1. General information:**

For a loose and emergency equipment check on all A320-271N, please follow up the below stated instructions.

In case of any findings e.g. low battery, missing safety cards and so on, please replace directly or open DD within 10 days for replacement.

ATTENTION:

This repetitive inspection covers MS Task 25.60.CLH.0005 which can't get deferred.

2. Effectivity:

MSN	AC Reg.
11150	D-AIJH
11238	D-AIJI
11299	D-AIJJ
11569	D-AIJM
11672	D-AIJN

3. Accomplishment:

Please check the loose and emergency equipment acc. to the following checklist.


3.1. General

ITEM	EACH	ACTION
Flashlights	7	<ul style="list-style-type: none">• Check for presence• Check batteries / function
Oxygen Panel (PSU)	60	<ul style="list-style-type: none">• Check for condition• Check door retainers to be flush
Safety Cards PN: SC-320N-1K-001	180	<ul style="list-style-type: none">• Check for presence at each single seat
Overwing Exit Briefing Cards PN: PSP-A32F-002	12	<ul style="list-style-type: none">• Check for presence at Overwing Exit Seats
Quick Reference Handbooks (QRHs) PN: QRH-A32F-001	4	<ul style="list-style-type: none">• Check for presence (2ea in front of CA1 and 2EA under CA3)
Safety & Emerg. Equip Checklist (EEC) PN: EEC-A320-001	4	<ul style="list-style-type: none">• Check for presence at FWD Galley 13, Stowage Comp. 02
Life Vest Pouch Seals PN: 631-0120	360	<ul style="list-style-type: none">• Check for presence• Check for sealing condition

3.2. Flight Deck

ITEM	EACH	ACTION
Observer Head Sets	1	<ul style="list-style-type: none"> Check for presence
TLB	1	<ul style="list-style-type: none"> Check TLB for expired or unapproved documents and discard if required
SDO Folder (Structure Damage Overview)	1	<ul style="list-style-type: none"> Check if SDO Folder is available in cockpit wardrobe behind CM1.


3.3. Cabin

GALLEY 13, STOWAGE COMP. 01		
ITEM	EACH	ACTION
First Aid Kit <u>Orange seal:</u> 	1	<ul style="list-style-type: none"> Check for presence Check if seal is broken Check expiry date → if expiry date is within the next 4 weeks, replace the kit <p>Attention:</p> <p>If the First Aid Kit is orange sealed, it can remain on board (do not change!) but if the First Aid Kit is yellow sealed, please replace it.</p> <p>Source: First Aid Manual (FAM) Kapitel 7, OM-B 10.1.7</p>


GALLEY 13, STOWAGE COMP. 02		
ITEM	EACH	ACTION
Demo Kit	1	<ul style="list-style-type: none"> Check for presence
Spares:		<ul style="list-style-type: none"> Check for presence
- Safety cards	10	
- Overwing Exit Briefing Cards	10	
Megaphone	1	<ul style="list-style-type: none"> Check for presence Check batteries / function



OVERHEAD COMPARTMENT 5ABC		
ITEM	EACH	ACTION
Portable Oxygen Bottles	3	<ul style="list-style-type: none">• Check for presence• Check pressure indication• If pressure is below 1600 psi → please replace the bottle or open DD and transfer for 10 days

CENTER CEILING STOWAGE (CCS)		
ITEM	EACH	ACTION
Doctors Kit <u>Yellow seal:</u> 	1	<ul style="list-style-type: none">• Check for presence• Check if seal is broken• Check expiry date → if expiry date is within the next 4 weeks, replace the kit <p>Attention: If the Doctor's Kit is in used condition (yellow sealed), please replace the kit immediately. Please check if TLB Entry was made.</p>
Wheelchair	1	<ul style="list-style-type: none">• Check for presence



SECOND TO LAST / LAST OVERHEAD COMPART. L/H SIDE		
ITEM	EACH	ACTION
Megaphone	1	<ul style="list-style-type: none">• Check for presence• Check batteries / function
First Aid Kit <u>Orange seal:</u> 	1	<ul style="list-style-type: none">• Check for presence• Check if seal is broken• Check expiry date → if expiry date is within the next 4 weeks, replace the kit <p>Attention:</p> <p>If the First Aid Kit is orange sealed, it can remain on board (do not change!) but if the First Aid Kit is yellow sealed, please replace it.</p> <p>Source: First Aid Manual (FAM) Kapitel 7, OM-B 10.1.7</p>
Demo Kit	2	<ul style="list-style-type: none">• Check for presence
Defibrillator	1	<ul style="list-style-type: none">• Check for presence
Portable Oxygen Bottles	3	<ul style="list-style-type: none">• Check for presence• Check pressure indication• If pressure is below 1600 psi → please replace the bottle or open DD and transfer for 10 days

LAVATORY (FWD & AFT)		
ITEM	EACH	ACTION
Waste Bin Fire Extinguisher	3 (in total)	<ul style="list-style-type: none">• Check for presence• Check of pressure gauge (needle is in green area)



3.4. A320-271N Cabin Layout

